

MITSUBISHI

Q62DA, Q64DA D/A Converter Module

Thank you for buying the Mitsubishi general-purpose programmable logic controller MELSEC Q Series.

Prior to use, please read both this manual and detailed manual thoroughly and familiarize yourself with the product.

User's Manual (Hardware)

MELSEC-Q

Mitsubishi Programmable
Logic Controller

MODEL	Q-D/A-U-H
MODEL Number	13JQ49

IB-0800033-F (0706) MEE

©1999 MITSUBISHI ELECTRIC CORPORATION

SAFETY PRECAUTIONS

(Read these precautions before using.)

When using Mitsubishi equipment, thoroughly read this manual and the associated manuals introduced in the manual. Also pay careful attention to safety and handle the module properly.

These precautions apply only to Mitsubishi equipment. Refer to the user's manual of the CPU module to use for a description of the PLC system safety precautions.

These SAFETY PRECAUTIONS classify the safety precautions into two categories: "DANGER" and "CAUTION".



Procedures which may lead to a dangerous condition and cause death or serious injury if not carried out properly.



Procedures which may lead to a dangerous condition and cause superficial to medium injury, or physical damage only, if not carried out properly.

Depending on circumstances, procedures indicated by CAUTION may also be linked to serious results.

In any case, it is important to follow the directions for usage.

Store this manual in a safe place so that you can take it out and read it whenever necessary. Always forward it to the end user.

DESIGN PRECAUTIONS

CAUTION

- Do not bunch the control wires or communication cables with the main circuit or power wires, or install them close to each other. They should be installed 100 mm (3.94 inch) or more from each other. Not doing so could result in noise that may cause malfunction.
- At power ON/OFF, voltage or current may instantaneously be output from the output terminal of this module. In such case, wait until the analog output becomes stable to start controlling the external device.

INSTALLATION PRECAUTIONS

CAUTION

- Use the PLC in an environment that meets the general specifications given in the User's Manual of the CPU module being used. Using this PLC in an environment outside the range of the general specifications may cause electric shock, fire, malfunction, and damage to or deterioration of the product.
- While pressing the installation lever located at the bottom of module, insert the module fixing tab into the fixing hole in the base unit until it stops. Improper installation may result in malfunction, breakdown or the module coming loose and dropping. Securely fix the module with screws if it is subject to vibration during using.
- Tighten the screws within the range of specified torque. If the screws are loose, it may cause the module to fall out, short circuits, or malfunction. If the screws are tightened too much, it may cause damage to the screw and/or the module, resulting in fall out, short circuits or malfunction.
- Be sure to shut off all phases of the external power supply used by the system before mounting or removing the module. Not doing so may cause damage to the module.
- Do not directly touch the conductive area or electronic components of the module. Doing so may cause malfunction or failure in the module.

WIRING PRECAUTIONS

CAUTION

- Always ground the FG terminal for the PLC. There is a risk of electric shock or malfunction.
- When turning on the power and operating the module after wiring is completed, always attach the terminal cover that comes with the product. There is a risk of electric shock if the terminal cover is not attached.
- Use applicable solderless terminals and tighten them with the specified torque. If any solderless spade terminal is used, it may be disconnected when the terminal screw comes loose, resulting in failure.
- Tighten the terminal screws within the range of specified torque. If the terminal screws are loose, it may result in short circuits or malfunction. If the terminal screws are tightened too much, it may cause damage to the screw and/or the module, resulting in short circuits or malfunction.
- Be careful not to let foreign matters such as sawdust or wire chips get inside the module. These may cause fires, failure or malfunction.
- The top surface of the module is covered with protective film to prevent foreign objects such as cable cuffs from entering the module when wiring. Do not remove this film until the wiring is complete. Before operating the system, be sure to remove the film to provide adequate heat ventilation.

About This Manual

The following manuals are also related to this product. Order them if necessary.

Related Manual

Manual Name	Manual No. (Model code)
D/A Converter Module User's Manual	SH-080054 (13JR02)

Conformance to the EMC Directive/Low Voltage Directive
When incorporating the Mitsubishi PLC into other machinery or equipment and keeping compliance with the EMC and low voltage directives, refer to Chapter 3, "EMC Directives and Low Voltage Directives" of the User's Manual (Hardware) included with the CPU module or base unit used.
The CE logo is printed on the rating plate on the main body of the PLC that conforms to the EMC directive and low voltage instruction.
By making this product conform to the EMC directive and low voltage instruction, it is not necessary to make those steps individually.

1. Overview

This manual explains specifications and the names of the components for the Q62DA type D/A converter module (hereafter Q62DA) and the Q64DA type D/A converter module (hereafter Q64DA) which are used in combination with the MELSEC-Q Series CPU module. In this manual, both the Q62DA and Q64DA are referred to as D/A converter modules.

2. Specifications


The specifications for the D/A conversion module are shown in the following table. For general specifications, refer to the operation manual for the CPU module being used.

Item	Type	Q62DA	Q64DA				
Number of analog outputs		2 points (2 channels)	4 points (4 channels)				
Digital input		16-bit signed binary (normal resolution mode: -4096 to 4095, high resolution mode: -12288 to 12287, -16384 to 16383)					
Analog output	Voltage	-10 to 10V DC (External load resistance 1 kΩ to 1 MΩ)					
	Current	0 to 20 mA DC (External load resistance 0 Ω to 600 Ω)					
I/O characteristics maximum resolution	Analog output range	Normal resolution mode					
		Digital input value	Maximum resolution				
		Voltage	0 to 5 V	0 to 4000	1.25 mV	0 to 12000	0.416 mV
			1 to 5 V		1.0 mV		0.333 mV
			-10 to 10 V	-4000 to 4000	2.5 mV	-16000 to 16000	0.625 mV
			Users range setting		0.75 mV	-12000 to 12000	0.333 mV
Current	Users range setting	High resolution mode					
		Digital input value	Maximum resolution				
		Voltage	0 to 5 V	0 to 4000	5 μA	0 to 12000	1.66 μA
			1 to 5 V		4 μA		1.33 μA
			-10 to 10 V	-4000 to 4000	1.5 μA	-12000 to 12000	0.83 μA
			Users range setting				
Accuracy (Accuracy in respect to maximum analog output value)	Ambient temperature 25 ± 5 °C	Within ± 0.1 % (Voltage : ± 10mV, Current : ± 20μA)					
	Ambient temperature 0 to 55 °C	Within ± 0.3 % (Voltage : ± 30mV, Current : ± 60μA)					
Conversion speed		80 μs/channel					

Item	Type	Q62DA	Q64DA
Absolute maximum output	Voltage	± 12 V	
	Current	21 mA	
Output short circuit protection		Available	
Insulation method	Between I/O terminal and PLC power supply	: Photocoupler insulation	
	Between output channels	: Not insulated	
	Between external supply power and analog output	: Not insulated	
Number of occupied points		16 points	
Connecting terminals		18 points terminal block	
Applicable wire size		0.3 to 0.75 mm ²	
Applicable solderless terminals		R1.25 - 3 (A solderless terminals with sleeves cannot be used)	
External supply power		24 V DC + 20 % - 15 %	
		Ripple, spike within 500 Vp-p	
	Inrush current : 1.9A, within 300μs	Inrush current : 3.1A, within 300μs	
Internal current consumption (5 V DC)		0.33 A	0.34 A
Weight		0.19 kg	

3. Part Names

This section explains the names of the components for the D/A conversion module.



Terminal number	Signal name			
	Q62DA		Q64DA	
1	V+	V+	V+	V+
2	CH1	COM	CH1	COM
3		I+		I+
4	Vacant		Vacant	
5	V+	V+	V+	V+
6	CH2	COM	CH2	COM
7		I+		I+
8	Vacant		Vacant	
9	Vacant			V+
10	Vacant		CH3	COM
11	Vacant			I+
12	Vacant		Vacant	
13	Vacant			V+
14	Vacant		CH4	COM
15	Vacant			I+
16			24 V	
17			24 G	
18			FG	

Number	Name	Description
1)	RUN LED	Displays the operating status of the D/A conversion module. On : Normal operation Flashing : During offset/gain setting mode Off : 5V power switched off, watchdog timer error occurred, or online module change enabled
2)	ERROR LED	Displays the error status of the D/A converter module. On : Error Off : Normal operation Flashing : Error in switch settings Switch No. 5 of the intelligent function module has been set to a value other than zero "0".
3)	External power supply terminal	This is the terminal for connecting the 24 V DC external power supply.

4. Handling Precautions

- Do not drop the module or cause it to receive strong impact.
- Tighten the terminal screws for the module to the specified torque shown below. Insufficient tightening torque could result in shorts, failures or malfunction.

Screw location	Tightening torque (M3 screw)
Module mounting screw (M3 screw)	0.36 to 0.48 N · m
Terminal block terminal screw (M3 screw)	0.42 to 0.58 N · m
Terminal block mounting screw (M3.5 screw)	0.66 to 0.89 N · m


5. Wiring

5.1 Wiring precautions


- Use separate cables for the external output signal or external power supply for the AC and D/A converter modules. Take steps to prevent the AC side from being affected by surge or inductance.
- Ground one point of the shield for shielded wires or shielded cables.

5.2 External wiring

- For voltage output



- For current output



*1 Use a twisted two core shielded wire for the power wire.

*2 If there is noise or ripples in the external wiring, connect a 0.1 to 0.47 m F25V condenser between the V+/I+ terminal and COM.

5.3 Switch setting for intelligent functional module


The settings for the intelligent function module are performed using the I/O allocation settings for the GX Developer. It can be easy to set by inputting using hexadecimal-4 digits.

Switch	Setting														
Switch 1	Output range setting <table border="1"> <tr> <th>Analog output range</th> <th>Output range setting value</th> </tr> <tr> <td>4 to 20 mA</td> <td>0H</td> </tr> <tr> <td>0 to 20 mA</td> <td>1H</td> </tr> <tr> <td>1 to 5 V</td> <td>2H</td> </tr> <tr> <td>0 to 5 V</td> <td>3H</td> </tr> <tr> <td>-10 to 10 V</td> <td>4H</td> </tr> <tr> <td>User range setting</td> <td>FH</td> </tr> </table>	Analog output range	Output range setting value	4 to 20 mA	0H	0 to 20 mA	1H	1 to 5 V	2H	0 to 5 V	3H	-10 to 10 V	4H	User range setting	FH
Analog output range	Output range setting value														
4 to 20 mA	0H														
0 to 20 mA	1H														
1 to 5 V	2H														
0 to 5 V	3H														
-10 to 10 V	4H														
User range setting	FH														
Switch 2	Not used														
Switch 3	HOLD/CLEAR function setting 0H : CLEAR 1 to FH : HOLD														
Switch 4	<table border="1"> <tr> <td>00h</td> <td>: Normal mode (non-synchronized)</td> </tr> <tr> <td>01 to FFh (numeric value other than 00h)</td> <td>: Synchronized output mode</td> </tr> <tr> <td>0h</td> <td>: Normal resolution mode</td> </tr> <tr> <td>1 to Fh (numeric value other than 0h)</td> <td>: High resolution mode</td> </tr> <tr> <td>0h</td> <td>: Normal mode (D/A conversion processing)</td> </tr> <tr> <td>1 to Fh (numeric value other than 0h)</td> <td>: Offset/gain setting mode</td> </tr> </table> The mode setting method is different from that of the function version A module. See point.	00h	: Normal mode (non-synchronized)	01 to FFh (numeric value other than 00h)	: Synchronized output mode	0h	: Normal resolution mode	1 to Fh (numeric value other than 0h)	: High resolution mode	0h	: Normal mode (D/A conversion processing)	1 to Fh (numeric value other than 0h)	: Offset/gain setting mode		
00h	: Normal mode (non-synchronized)														
01 to FFh (numeric value other than 00h)	: Synchronized output mode														
0h	: Normal resolution mode														
1 to Fh (numeric value other than 0h)	: High resolution mode														
0h	: Normal mode (D/A conversion processing)														
1 to Fh (numeric value other than 0h)	: Offset/gain setting mode														
Switch 5	0 : Fixed														

* Setting any value within the setting range will provide the same operation. When the setting range is 1 to FH, set 1 for example.

Point
Setting of the offset/gain setting mode differs for function version A and function version B. In the offset/gain setting mode, confirm that the RUN LED is flickering, and then set the offset/gain. If the RUN LED is not flickering, check whether switch 4 is set correctly.

6. External Dimensions



unit (mm (in.))

Warranty

Mitsubishi Electric shall not be liable for any loss caused by reasons for which Mitsubishi is not held accountable, lost business opportunities or unrealized gain on the customer's side resulting from failure of the product, or any other damage, secondary disaster, accident, damage to equipment other than the product or disruption of other business operations arising out of special circumstances which may or may not have been predicted at Mitsubishi.

For safe use of the product

- This product is manufactured as a general-purpose product intended for general industrial use only. It is not designed nor manufactured for use in an equipment or system affecting human lives.
- If you are considering to use this product in equipment or systems for nuclear power generation, power generation, aerospace, medical or passenger transport applications, consult our sales representatives.
- This product is manufactured under our strict quality control system. However, if the product is used in the intended facility in such a way that a failure of the product may lead to serious accident or loss, incorporate backup or fail-safe functions into the system design.

Country/Region	Sales office/Tel	Country/Region	Sales office/Tel
U.S.A	Mitsubishi Electric Automation Inc. 500 Corporate Woods Parkway Vernon Hills, IL 60061 Tel : +1-847-478-2100	Hong Kong	Ryoden Automation Ltd. 10th Floor, Manulife Tower, 169 Electric Road, North Point, HongKong Tel : +852-2387-8870
Brazil	MELCO-TEC Rep. Com.e Assessoria Tecnica Ltda. Rua Correia Dias, 184, Edifício Paraiso Trade Center-8 andar Paraiso, Seo Paulo, SP Brazil Tel : +55-11-5508-8331	China	Ryoden Automation Shanghai Ltd. 3F Block5 Building Automation Instrumentation Plaza 103 Cao Bao Rd. Shanghai 200233 China Tel : +86-21-6120-0808
Germany	Mitsubishi Electric Europe B.V. German Branch Gothaer Strasse 8 D-40880 Ratingen, GERMANY	Taiwan	Setsuyo Enterprise Co., Ltd. 6F., No. 105 Wu-Kung 3rd Rd, Wu-Ku Hsiang, Taipei Hsine, Taiwan Tel : +886-2-2259-2499
UK	Mitsubishi Electric Europe B.V. UK Branch Travelers Lane, Hatfield, Herts., AL 10 8XB UK Tel : +44-1707-276100	Korea	HAN NEUNG TECHNO CO.,LTD. 1F Dong Seo Game Channel Bldg., 660-11, Deungchon-dong Kangseok-ku, Seoul, Korea Tel : +82-2-3680-9552
Italy	Mitsubishi Electric Europe B.V. Italian Branch Centro Dir. Colleoni, Pal. Perseo-Ing.r 2 Via Paracelso 12, 20041 Agrate B., Milano, Italy Tel : +39-039-605344	Singapore	Mitsubishi Electric Asia Pte. Ltd. 307 Alexandra Road #05-01/02, Mitsubishi Electric Building Singapore 159943 Tel : +65-6473-2308
Spain	Mitsubishi Electric Europe B.V. Spanish Branch Carretera de Rubi 76-80 08190 Sant Cugat del Valles, Barcelona, Spain Tel : +34-93-565-3131	Thailand	F. A. Tech Co.,Ltd. 898/28,29,30 S.V.City Building,Office Tower 2, Floor 17-18 Rama 3 Road, Bangkokpang, Yannaawa, Bangkok 10120 Tel : +66-2-682-6522
France	Mitsubishi Electric Europe B.V. French Branch 25 Boulevard des Bouvets, F-92741 Nanterre Cedex, France TEL : +33-1-5568-5568	India	P. T. Autolekindo SUMBER MAKMUR Jl. Muara Karang Selatan Block a Utara No.1 Kav. No.11 Kawasan Industri/Perdagangan Jakarta - Utara 14440 Tel : +62-21-663-9833
South Africa	Circuit Breaker Industries LTD. Tripswitch Drive, Elandsfontein Gauteng, South Africa Tel : +27-11-928-2000	Australia	Electronic Sdan NO.111 Unit No 15, M.I.D.C BHOSARU,PUNE-411026, India Tel : +91-20-712-2807 Mitsubishi Electric Australia Pty. Ltd. 348 Victoria Road, PostalBag, No 2, Rydalmere, N.S.W 2116, Australia Tel : +61-2-9684-7777

MITSUBISHI ELECTRIC CORPORATION

HEAD OFFICE : 1-8-12, OFFICE TOWER 21F HARBOR CITY BLDG.104-8212, JAPAN
INDONESIA OFFICE : 1-14, YUDA MANSION SCHEME, HOOGHSHI HILL, JAKARTA, INDONESIA

When exported from Japan, this manual does not require application to the Ministry of Economy, Trade and Industry for service transaction permission.

Specifications subject to change without notice.
Printed in Japan on recycled paper.