


### Connection accessories (Cu or Al)

#### Rear connections

DB11225



2 short	LV432475
2 long	LV432476

#### Cable connectors <sup>(1)</sup>

EZ2040



Aluminium connector 1x (35 to 300 mm <sup>2</sup> )	Set of 3	LV432479
	Set of 4	LV432480

EZ2041



Aluminium connector 2x (35 to 240 mm <sup>2</sup> )	Set of 3	LV432481
	Set of 4	LV432482

Voltage plug for aluminium connector 1 or 2 cables	Set of 10	LV429348
--	-----------	----------

#### Terminal extension <sup>(1)</sup>

E21012



Spreaders	52.5 mm	3P	LV432490
		4P	LV432491
	70 mm	3P	LV432492
		4P	LV432493

#### Insulation accessories

E18618



Short terminal shield, 45 mm (1 piece)	3P	LV432591
	4P	LV432592

E18606



Long terminal shield, 45 mm (1 piece)	3P	LV432593
---------------------------------------	----	----------



Interphase barriers	Set of 6	LV432570
---------------------	----------	----------



Long terminal shield for spreaders, 52,5mm (1 piece) (supplied with insulating plate)	3P	LV432595
---	----	----------

2 insulating screens (70 mm pitch)	4P	LV432596
	3P	LV432578
	4P	LV432579

<sup>(1)</sup> supplied with 2 or 3 interphase barriers

### Electrical auxiliaries

#### Auxiliary contacts (changeover)

E18608



OF or SD or SDE or SDV	29450
OF or SD or SDE or SDV low level	29452

#### Voltage releases



	Voltage	MX	MN
AC	110-130 V 50/60 Hz	LV429386	LV429406
	220-240 V 50/60 Hz and 208-277 V 60 Hz	LV429387	LV429407
	380-415 V 50 Hz and 440-480 V 60 Hz	LV429388	LV429408
DC	Voltage		
	24 V	LV429390	LV429410