
# **Xenon Strobe Light**

# S150US/ S150US-FT S150UHS/ S150UHS-FT
















## Precautions for Safety

Failure to follow the instructions below may cause a loss of life or serious physical injury.

- 1. During wiring or maintenance, please completely turn off the power of the product. (Failure to follow this may lead to an electric shock.)
- 2. Do not install the product in locations that subjects it to excessive dust or water other than the conditions designated by the IP protection ratings indicated for each product. (Failure to follow these instructions may cause a fire to the product, electric shock, physical injury, malfunction or damage to the product.)
- 3. Do not alter or repair this product. If maintenance or repair service is required, please contact your local Qlight contact point. (Failure to follow these instructions may lead to fire, electric shock, or product damage.)
- 4. Please apply the correct voltage to the product. (Failure to follow these instructions may lead to fire, electric shock, or product damage.)
- 5. When the product is applied to a condition that may impact lives or property, please make sure to have a double safety device. (Failure to follow this may cause damage to property, fire, electric shock and loss of life.)

## **▲** Precautions for Correct Use

Failure to follow the proper instructions may cause damage to property, the product, or malfunction of the product that would void the warranty.

- 1. Please remove any objects that can interrupt ventilation around the product.
- 2. Please turn off the power of the product immediately if it fails to operate properly.
- 3. Carefully wire the product according to each product's specification.
- 4. Please be careful in preventing chemicals such as thinner, benzene, etc. in contact with the surface of the product.
- 5. Do not apply excessive force/impact to the product.
- 6. Failure to follow any of the instructions above may cause malfunction or damage to the product, fire, and electric shock.

#### **Ordering Specifications**

#### S150US ΒZ 220 [Model [Voltage] [Buzzer] [Color] number] R-Red • S150US • (Blank) - No buzzer type S150US-FT -DC12V~24V A-Amber G-Green S150UHS 110 - AC110V - Built-in buzzer B-Blue • S150UHS-FT • 220 - AC220V type

#### **Product Specifications**

Model	Voltage	Current	Bulb specifications					
number			Volts/ Watts	Configuration	Part#	Certificate	Weight	Color
S150US S150US-FT	DC12V ~24V	Max. 1.000A	200V	EUB0641 -1A(G)	48	-	0.56kg	
	AC110V	0.135A	~550V	U type			0.54kg	
	AC220V	0.105A						
S150UHS S150UHS- FT	DC12V	1.277A			40		0.78kg	
	DC24V	0.655A	280V	BH0647(G)				
	AC110V	0.270A	-400V	W type			0.69kg	
	AC220V	0.218A						


- Protection rating : IP44
- Ambient operating temperature : -30°C to +50°C




Please scan the QR code for more detailed product information.


**Dimensions** (Units:mm)


#### S150US/ S150UHS







#### S150US-FT/ S150UHS-FT





# **Wiring Instructions**






- External power line UL1015 AWG18(0.75sq) x 2C 400mm
- This product can be wired regardless of polarity.
- For built-in buzzer type, once the unit is powered on, singal light and buzzer are working simultaneously.

## Parts Definition/Installation

### ■Parts Definition




#### ■Installation

- First, remove the flange nuts from bolts and place the product through the mounting surface holes (S150US only).
- Fasten the flange nuts on the opposite side of the mounting surface until the product is tightened securely.


## Mounting Hole Specifications/ Xenon Bulb Replacement Instructions

#### ■Mounting Hole Specifications

 Machine holes on the mounting surface referring to the diagram below.





S150US/ S150UHS




S150US-FT/ S150UHS-FT

#### ■Xenon Bulb Replacement instructions





#### S150UHS/ S150UHS-FT



- Please wait at least 30 mimutes after turning off the power before replacing the xenon bulb.
- Please pull out the entire xenon bulb structure ① to disassemble.
- •For xenon bulb assembly, please ensure the connector portion of the xenon bulb structure matches the pin location 2.

## Installation Environment and Protection Rating

- This product is designed for use with protection rating of IP44.
- If the product is installed in locations that subject it to excessive dust or water other than the designated IP protection rating indicated(IP44), it may cause malfunction or damage to the product.
- In case of outdoor applications, install the product in the upright position. Do not install the product horizontal or upside-down positions where water can potentially penetrate into the product and impact it's operation.
- For further information, please visit our website (www.qlight.com).



Specification and dimensions listed in this catalogue subject to change without notice for product quality improvement. The newest product information is available on our website.(www.qlight.com)

Please read the instruction manual attached to the product carefully before installation and use.

#### Qlight Co., Ltd. www.qlight.com | trade@qlight.com

Head Office | Suite #1510, STX-V Tower, 128 Gasan digital 1-ro, Geumcheon-gu, Seoul, Korea

Tel. +82-2-2679-6152(Toll free. +82-80-328-2222) Fax. +82-2-2679-6154

Factory | 185-25, Mukbang-ro, Sangdong-myeon, Gimhae-si, Gyeongsangnamdo, Korea Tel. +82-55-328-1111(Toll free. +82-80-328-1111)

Qlight OverSEAs Sales Dept | 704 Nakdong-daero, Sasang-gu, Busan, Korea(Eomgung-Dong) Tel: +82-51-620-4100

Qlight Public Relations & Marketing Team Office | 704 Nakdong-daero, Sasang-gu, Busan, Korea(Eomgung-Dong) Tel. +82-51-245-0017

#### $Qlight\ USA,\ Inc.\quad www.qlight.com\ \ www.qlightusa.com\ |\ sales@qlightusa.com\ |$

3003 North First Street, Suite #341, San Jose, CA 95134 USA Tel. +1-408-519-5740 Fax. +1-408-519-5739

## $SHANGHAI\ Qlight\ Electronic\ Co.,\ Ltd.\ www.qlight.com\ \ www.qlightcn.com\ |\ qlightcn@qlight.com$

China Factory/ Shanghai Sales Office | #19, Nanda Road, Baoshan Area, Shanghai, China Tel. +86-21-6651-7100 Fax. +86-21-6315-3929 China Factory Site 2 (Qidong) | #33, Haiyan Road, Qidong High-tech Industrial Development Zone, Qidong, Jiangsu Province, China Tel +86-513-8384-9999 Fax +86-513-8384-9910



Product Operation Inquiry / Customer Support +82-51-620-4100

You can expect prompt service if you have exact information such as model name, symptom, telephone number and address.

\*\*ALL PRODUCT, PRODUCT SPECIFICATIONS AND DATA ARE SUBJECT TO CHANGE WITHOUT NOTICE TO IMPROVE

RELIABILITY FUNCTION OR DESIGN OR OTHERWISE

RELIABILITY, FUNCTION OR DESIGN OR OTHERWISE.

Head office: Suite #1510, STX-V Tower, 128 Gasan digital 1-ro, Geumcheon-gu, Seoul, Korea (Postal Code: 08507)

Factory: 185-25, Mukbang-Ro, Sangdong-Myeon, Gimhae-Si, Gyeongsangnam-Do, Korea (Postal Code: 50805)

# **LED Steady/ Flashing Signal Light**

# **S150RL(FT)/ S150UL(FT)**














Thank you for purchasing Qlight's products. Please read this user manual carefully prior to installation and operation to ensure safe and correct use.

## Precautions for Safety

Failure to follow the instructions below may cause a loss of life or serious physical injury.

- 1. During wiring or maintenance, please completely turn off the power of the product. (Failure to follow this may lead to an electric shock.)
- 2. Do not install the product in locations that subjects it to excessive dust or water other than the conditions designated by the IP protection ratings indicated for each product. (Failure to follow these instructions may cause a fire to the product, electric shock, physical injury, malfunction or damage to the product.)
- 3. Do not alter or repair this product. If maintenance or repair service is required, please contact your local Qlight contact point. (Failure to follow these instructions may lead to fire, electric shock, or product damage.)
- 4. Please apply the correct voltage to the product. (Failure to follow these instructions may lead to fire, electric shock, or product damage.)
- 5. When the product is applied to a condition that may impact lives or property, please make sure to have a double safety device. (Failure to follow this may cause damage to property, fire, electric shock and loss of life.)

### ▲ Precautions for Correct Use

Failure to follow the proper instructions may cause damage to property, the product, or malfunction of the product that would void the warranty.

- 1. Please remove any objects that can interrupt ventilation around the product.
- 2. Please turn off the power of the product immediately if it fails to operate properly.
- 3. Carefully wire the product according to each product's specification.
- 4. Please be careful in preventing chemicals such as thinner, benzene, etc. in contact with the surface of the product.
- 5. Do not apply excessive force/impact to the product.
- 6. Failure to follow any of the instructions above may cause malfunction or damage to the product, fire, and electric shock.

## **Ordering Specifications**

S150UL	BZ	. 220	·R
[Model number]	[Buzzer]	[Voltage]	[Color]
I I	1	1	1
• \$150RL • \$150RL-FT • \$150UL • \$150UL-FT	(Blank)     - No buzzer type     BZ     - Built-in buzzer type	• 12/24 -DC12V-24V • 110 -AC110V • 220 -AC220V	R-Red A-Amber G-Green B-Blue

Model number S150RL(-FT) does not support built-in buzzer option.

#### **Product Specifications**


Model number	Voltage	Current	Certificate	Weight	Color
S150RL S150RL-FT	DC12V	Max.		0.64kg	R-Red A-Amber G-Green B-Blue
	-24V	0.300A			
	AC110V	0.060A		0.92kg	
	AC220V	0.030A			
S150UL S150UL-FT	DC12V	Max.	-	0.52kg	
	-24V	0.300A		0.52kg	
	AC110V	0.060A		0.92kg	
	AC220V	0.030A		0.92kg	

- Protection rating : IP44
- Ambient operating temperature : -20°C to +50°C




Please scan the QR code for more detailed product information.

**Dimensions** (Units: mm)



# **Wiring Instructions**




- External power line UL1015 AWG18(0.75sq) × 2C 400mm
- This product can be wired regardless of polarity.
- For built-in buzzer type, there is a shared supply line for the buzzer and lighting element.

Power


## Parts Definition/ Installation/ Light Function Selection


#### ■ Parts Definition



#### ■ Light Function Selection

• Please refer to the diagram below to use light function switch located inside the product.





▶ L : Steady

▶ LF : Flashing


· Default setting is set as steady LED function. During installation, please select the desired light function according to your application needs.

#### ■ Installation


- First, remove the flange nuts from bolts and place the product through the mounting surface holes. (S150RL/ S150UL only)
- · Fasten the flange nuts on the opposite side of the mounting surface until the product is tightened securely.

## **Mounting Hole Specifications**

• Machine holes on the mounting surface referring to the diagram below.




S150RL/ S150UL



S150RL-FT/S150UL-FT

## Installation Environment and Protection Rating

- This product is designed for use with protection rating of IP44.
- If the product is installed in locations that subject it to excessive dust or water other than the designated IP protection rating indicated(IP44), it may cause malfunction or damage to the product.
- In case of outdoor applications, installation in the upright position is suggested to minimize the effect of rain on the product.
- For further information, please visit our website (www.qlight.com).



Specification and dimensions listed in this catalogue subject to change without notice for product quality improvement. The newest product information is available on our website.(www.qlight.com)

Please read the instruction manual attached to the product carefully before installation and use.

#### Qlight Co., Ltd. www.qlight.com | trade@qlight.com

Head Office | Suite #1510, STX-V Tower, 128 Gasan digital 1-ro, Geumcheon-gu, Seoul, Korea

Tel. +82-2-2679-6152(Toll free. +82-80-328-2222) Fax. +82-2-2679-6154

Factory | 185-25, Mukbang-ro, Sangdong-myeon, Gimhae-si, Gyeongsangnamdo, Korea Tel. +82-55-328-1111(Toll free. +82-80-328-1111)

Qlight OverSEAs Sales Dept | 704 Nakdong-daero, Sasang-gu, Busan, Korea(Eomgung-Dong) Tel: +82-51-620-4100

Qlight Public Relations & Marketing Team Office | 704 Nakdong-daero, Sasang-gu, Busan, Korea(Eomgung-Dong) Tel. +82-51-245-0017

#### Qlight USA, Inc. www.qlight.com www.qlightusa.com | sales@qlightusa.com

3003 North First Street, Suite #341, San Jose, CA 95134 USA Tel. +1-408-519-5740 Fax. +1-408-519-5739

## $SHANGHAI\ Qlight\ Electronic\ Co.,\ Ltd.\ www.qlight.com\ \ www.qlightcn.com\ |\ qlightcn@qlight.com$

China Factory/ Shanghai Sales Office | #19, Nanda Road, Baoshan Area, Shanghai, China Tel. +86-21-6651-7100 Fax. +86-21-6315-3929 China Factory Site 2 (Qidong) | #33, Haiyan Road, Qidong High-tech Industrial Development Zone, Qidong, Jiangsu Province, China Tel +86-513-8384-9999 Fax +86-513-8384-9910



Product Operation Inquiry / Customer Support +82-51-620-4100

You can expect prompt service if you have exact information such as model name, symptom, telephone number and address.

\*\*ALL PRODUCT, PRODUCT SPECIFICATIONS AND DATA ARE SUBJECT TO CHANGE WITHOUT NOTICE TO IMPROVE

RELIABILITY FUNCTION OR DESIGN OR OTHERWISE

RELIABILITY, FUNCTION OR DESIGN OR OTHERWISE.

Head office: Suite #1510, STX-V Tower, 128 Gasan digital 1-ro, Geumcheon-gu, Seoul, Korea (Postal Code: 08507)

Factory: 185-25, Mukbang-Ro, Sangdong-Myeon, Gimhae-Si, Gyeongsangnam-Do, Korea (Postal Code: 50805)