Flat Area Sensor With Plastic Case

Features

- 13mm slim body with fresnel lens
- Adoption of plastic (polycarbonate, acrylonitrile butadiene styrene) injection case
- Various functions; stop transmission, interference prevention, lightening/flashing JOB indicator, Light ON/Dark ON operation by switch
- Easy to recognize at side, front, and long-distance by high brightness LED of Emitter and Receiver
- Fast response time up to 7ms
- 4 models with various optical axes (8 to 20) and sensing height (140 to 380mm)
- Protection structure IP40 (IEC standard)



manual before using. Specifications

						Temperatu		
Model	NPN open collector output	BWP20-08	BWP20-12	BWP20-16	BWP20-20	Controller		
	PNP open collector output	BWP20-08P	BWP20-12P	BWP20-16P	BWP20-20P	(I) SSRs / Po Controller		
Sensing type		Fhrough-beam type						
Sensing distance		0.1 to 5m	0.1 to 5m					
Sensing target		Opaque materials of m	Opaque materials of min. Ø30mm					
Optical axis pitch		 20mm						
Number of o	otical axis	8	12	16	20			
Sensing heig	ht	140mm	220mm	300mm	380mm	(L) Panel		
Power supply	y	12-24VDC ±10% (rippl	12-24VDC ±10% (ripple P-P: max. 10%)					
Current cons	umption	Emitter: max. 80mA, R	Receiver: max. 80mA			(M) Tacho /		
Control output		NPN or PNP open collector output • Load voltage: max. 30VDC • Load current: max. 150mA • Residual voltage - NPN: max. 1V, PNP: min. 2.5V						
Protection ci	rcuit	Reverse polarity protect	Reverse polarity protection circuit, output short over current protection circuit					
Operation me	ode	Switching of Light ON/Dark ON by switch						
Response time		Max. 6ms (frequency B selection is max. 7ms)						
Light source		Infrared LED (850nm modulated)						
Synchronization type		Timing method by synchronous line						
Interference protection		Interference protection by transmission frequency selection						
	Ambient illumination	Ambient light: max. 10,0001x (received light side illumination)						
Environment	Ambient temperature	-10 to 55°C, storage: -20 to 60°C						
	Ambient humidity	35 to 85%RH, storage: 35 to 85%RH						
Noise immur	nity	$\pm 240V$ the square wave noise (pulse width 1µs) by the noise simulation						
Dielectric stre	ength	1,000VAC 50/60Hz for 1 minute						
Insulation resistance		Over 20MΩ (at 500VDC megger)						
Vibration		1.5mm amplitude at frequency of 10 to 55Hz in each X, Y, Z direction for 2 hours						
Shock		500m/s² (approx. 50G) in each X, Y, Z direction for 3 times						
Protection structure		IP40 (IEC standard)						
Material		Case: Polycarbonate/Acrylonitrile butadiene styrene, Sensing part: Polymethyl methacrylate						
Cable		Ø3.5mm, 4-wire, 3m (AWG24, core diameter: 0.08mm, number of cores: 40, insulator out diameter: Ø1mm)						
Approval		CE						
Weight ^{**1}		Approx. 480g (approx. 280g)	Approx. 520g (approx. 320g)	Approx. 620g (approx. 360g)	Approx. 680g (approx. 430g)			

X1: The weight includes packaging. The weight in parenthesis is for unit only.

*The temperature or humidity mentioned in Environment indicates a non freezing or condensation.





(C) Door/Area Sensors

(D) Proximity Sensors

(E) Pressure Sensors

(F) Rotary Encoders

(G) Connectors/ Connector Cables/ Sensor Distribution Boxes/Sockets

(H)

ture ers

owei ers

g wer

Motors llers



Dimensions

υ



(unit: mm) <Bracket>: sold separately • Flat bracket (BK-BWP-ST) • L-shaped bracket (BK-BWP-L) • Protection bracket (BK-BWP-P_) 75 36.6 41 50 18 21.6 16 18 15 67 -À 3 5 20 2 \subset 32 35 15 5 Ø2.2 Ø2.2 -@-A 2-4.6 2-4.6 Ð 10.6 60 10.6 4 œ. 2-Ø3 2-Ø5 1.6 Model Α BK-BWP-P08 194 35 BK-BWP-P12 274 13.5 BK-BWP-P16 354 17.5 BK-BWP-P20 434

Autonics

Feature Data



Input/Output Circuit And Connection Diagram



the emitter is not operated and maintain the light status.

Timing Diagram Operation



Ş

Output short over current

protection circuit

Main circuit

(blue) 0V

(brown) +V

(black) OUT

(blue) 0V

Load



(H) Temperature Controllers

(I) SSRs / Powe Controllers

(J) Counters

(N) Display Units (O) Sensor Controllers

(P) Switching Mode Power Supplies

(Q) Stepper Motors & Drivers & Controllers

(R) Graphic/ Logic Panels

(S) Field Network Devices

(T) Software



※If the receiver OUT (black) line and the emitter JOB (black) line are not connected each other, the JOB indicator of

%The waveforms of operation indicator, job indicator, and control output are the state of operation for Light ON, but in case of Dark ON, it is opposite operation against Light ON mode.



Structure



O Mounting of bracket

No.	Function	Switch OFF	Switch ON
1	Transmission frequency selection	Frequency A	Frequency B
2	Light ON/Dark ON selection	Light ON operation	Dark ON operation
3	Steady/flashing light of Job indicator selection	Job indicator with Steady light	Job indicator with Flashing light
4	JOB/TEST selection	Normal mode	TEST mode

Functions

◎ TEST (stop transmission)

When selecting TEST mode, emit is stopped and green &orange LED of emitter flashes. It is available to check whether sensor operates properly with stopping the transmission in TEST mode. It is changed to light OFF status when emit the transmission is stopped, control output is OFF in Light ON mode and ON in Dark ON mode.

Control output pulse for TEST input



◎ Interference prevention

In case of using 2 of sensor in serial or parallel in order to extend sensing width, it may cause sensing error because of light interference.

This function is operating a sensor in transmission frequency A and another sensor in transmission frequency B to avoid these sensing errors by the light interference.



© Light-ON / Dark-ON operation mode

The control output is ON when it is light ON in Light ON and the control output is ON when it is light OFF in Dark ON. It is available to select with user's preference.

	Operation mode switch	Control output operation		
Light ON	ON ← ④ □ □ ③ □ □ Light ON	It is ON when it is light ON.		
Dark ON	ON ← ④ □ □ ② ■ □ Dark ON ① □ □	It is ON when it is light OFF.		

© Lightening/Flashing JOB indicator

JOB indicator will be lighted and flashed to make out work sensing operation more easily.

	Operation mode switch	JOB indicator operation		
Lighting	4 ☐ Lighting 2 ☐ 1 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0	Lighting indicator		
Flashing	Gashing ③ ③ ④ ①	Flashing indicator		

(A) Photoelectric Sensors

(B) Fiber Optic Sensors

r/Area

butior

(N) Display Units

(C)

Installation

O For direction of installation

Emitter and receiver should be installed as same up/down position.



O For reflection from the surface of wall and flat

When installing it as below the light reflected from the surface of wall and flat will not be shaded. Please, check whether it operates normally or not with a sensing target before using. (interval distance: min. 0.3m)



O For prevention of interference

It may cause interference when installing more than 2 sets of the sensor. In order to avoid the interference of the sensor, please install as following figures and use the interference protection function.

• Transmission direction should be opposite between 2 sets





• It should be installed out of the interference distance



Operation Indicator

Operation Indicator						(D) Proximity Sensors			
	Emitter			Receiver					
hom	Indicator			Indicator			Control	(E) Pressure	
lem	Green	Orange	JOB Indicator	Green	Red	JOB Indicator	output	Sensors	
Power on	Φ.		—	—	—	—	_	(F)	
Frequency A pperation	Þ.	•	_	_	—	_	_	Encoders	
Frequency B pperation	¢	¢	_	—	—	_	_	(G) Connectors/ Connector Cal Sensor Distrib Boxes/Sockets	
EST	۲	۲	ф.	<u>ې</u>		Ċ.	OFF		
Stable light ON	—	—	•	¢.	¢	•	ON	(H)	
Jnstable light ON	—	—	•	•	Ø		ON	Temperature Controllers	
Jnstable light OFF	FI		¢	OFF					
Stable light OFF	—	—	ф	ф		ф.	OFF	(I) SSRs / Pow	
lashing function ON	—	—	•	¢		•	OFF	Controllers	
Synchronous line nalfunction	chronous line		¢	۲	۲	¢	OFF	(L)	
Overcurrent	—	—	ф	0	\bullet	\¢	OFF	Counters	
Display classificatio	n list								
Č- Light ON							(K) Timers		
•	Light OFF								
Flashing by 0.3 sec								(L)	
•••	Flashing simultaneously by 0.3 sec							Panel Meters	
•	Cross-Flashing by 0.3 sec								
The operation of Control output	of 'Ope ' is for	ration Light (indicator DN, in ca	r (red)' ise of l	, 'Job Dark (indicato ON, it is	r (red)', opposite	(M) Tacho / Speed / Pul Meters	

*The operation of 'Operation indicator (red)', 'Job indicator (red)', 'Control output' is for Light ON, in case of Dark ON, it is opposite operation against Light ON. (In case, malfunction of synchronous line and over current, control output is OFF regardless of the mode.)

Troubleshootina

			(0)
Malfunction	Cause	Troubleshooting	Sensor
	Power supply	Supply rated power.	Controllers
	Cable incorrect		
Non-operation	connection or	Check the wiring.	(P) Switching
Non-operation	disconnection		Mode Power
	Rated connection failure	Use it within rated sensing distance.	Supplies
	Pollution by dirt of	Remove dirt by soft brush or	Stepper Motor
Non-operation	sensor cover	cloth.	& Drivers
in sometimes	Cable connection failure	Check the assembled part of the cable.	(R)
	Out of rated sensing	Use it within rated sensing	Graphic/
	distance	distance.	Panels
	There is an obstacle to		
	cut off the light emitted		(S)
Control output is OFF	between emitter and	Remove the obstacle.	Network
even though there is	receiver		Devices
not a target object.	There is a strong electric		
	wave or noise generator	Dut owny the strong cleatric	(T)
	such as motor, electric	Put away the strong electric	Software
	generator, high voltage	wave of horse generator.	
	line etc.		
	Synchronous line		
I ED displays for	incorrect connection or	Check the wiring.	
synchronous line	disconnection		
malfunction	Break of synchronous		
	circuit of emitter or	Contact our company.	
	receiver		
	Control output line is	Check the wiring	
LED displays for over	shorten		
current	Over load	Check the rated load	
1	0.00.0000	capacity.	

Autonics