APEM

Switches &

Pilot Lights

Emergency

Enabling Switches

Stop Switches

Safety Products

Explosion Proof

Terminal Blocks

Relays & Sockets Circuit Protectors Power Supplies LED Illumination Controllers Operator Interfaces Sensors AUTO-ID

# FB Series Control Stations

## IP65 lightweight control stations. IDEC HW and XW series switches and pilot lights installed.

- ø22 mm switches/pilot lights can be installed.
- Blank front enclosures, without mounting holes, are also available.
- Blank front enclosures can also be used as junction boxes to mount terminal blocks.
- Yellow cover enclosures for emergency stop switches are also available.
- · Front panel mounting, rear panel mounting, hook mounting, and frame mounting options are available.

<sub>c</sub>(UL)<sub>us</sub> CE LISTED

- Contact cover box (Part no.: FB1WBR) is not UL or c-UL listed.
- Enclosures without mounting hole is not UL or c-UL listed.
- (Enclosures less than 1,639 cm<sup>3</sup> is not approved by UL50, 2:8.)
- · See website for details on approvals and standards.

Enclos	ures		Package Quantity:	
Size	No. of Mounting Holes	Mounting Hole Description	Cover Color (*1)	Part No.
	0	Without mounting hole	Light beige	FB1T-000Z
76mm	1	ø22mm	Yellow	FB1W-111Y
	1	ø22mm	Light beige	FB1W-111Z
	0	Without mounting hole	Light beige	FB2T-000Z
140mm	2	ø22mm, mounting centers 50mm	Light beige	FB2W-211Z
	3	ø22mm, mounting centers 30mm	Light beige	FB2W-312Z
	0	Without mounting hole	Light beige	FB3T-000Z
200mm	3	ø22mm, mounting centers 50mm	Light beige	FB3W-311Z
200/11/11	4	ø22mm, mounting centers 36mm	Light beige	FB3W-413Z
	5	ø22mm, mounting centers 30mm	Light beige	FB3W-512Z

\*1) Light beige (Munsell 5Y7/1 or equivalent), Yellow (Munsell 2.5Y8/10 or equivalent), Enclosure base color: Black (Munsell N1.5 or equivalent)



1	Contact Cover Box Package Quantity: 1						
	Size	No. of Mounting Holes	Mounting Hole Description	Cover Color	Part No.		
	76mm	1	ø22 mm hole in the base	Light beige	FB1WR-111Z		
,	For operating instructions, see C-019.						

#### Accessories

Description	Part No.	Ordering No.	Package Quantity
Mounting Bracket	FB9Z-PK1	FB9Z-PK1	1
DIN Rail Adapter	FB9Z-PK3	FB9Z-PK3PN02	2
Mounting Hole Plug	LW9Z-BP1	LW9Z-BP1	1

· Connectors and nuts are supplied by users.


## Specifications (\*2)

Applicable Standards	IEC/EN60529 UL508 UL50 CSA C22.2 No. 14 CSA C22.2 No. 94
Standard Operating Conditions	Ambient temperature:       -25 to +60°C (no freezing)         Relative humidity:       45 to 85%RH (no condensation)         Storage temperature:       -40 to +80°C (no freezing)         Degree of pollution:       3
Degree of Protection	IP65 (when IP65 switches/pilot lights are installed) NEMA Type 4X Indoor Use Only (when Type 4X switches/pilot lights are installed)
Electric Shock Protection	Class II (when class II switches/pilot lights are installed)
Material	Box cover / box base: polycarbonate (*5) Box cover mounting screw: stainless
Applicable Switches/ Pilot Lights	IDEC's HW/TW/XW series and accessories (*3) (*4)
Weight (approx.)	76 mm: 125g (FB1W-111Y) 140 mm: 184g (FB2W-211Z) 200 mm: 243g (FB3W-311Z)

\*2) The above specifications are for enclosures. For switches/pilot lights, refer to the specifications of each unit.


\*3) Choose switches/pilot lights and accessories which match the mounting hole centers, effective depth behind the cover, and the thickness of the cover where switches/pilot lights are installed (3 mm). Note that enclosures with 30 mm or 36 mm mounting hole centers may limit the knob orientation of selector switches, because the contact blocks can be mounted in one direction only on these mounting centers.

- \*4) An XW series emergency stop switch of screw terminal model can be installed on an enclosure with one mounting hole or mounting holes of 50 mm mounting centers, by connecting one clamping terminal to one terminal pole. \*5) Flame-resistant (UL94V-0).




All dimensions in mm.

#### **Dimensions**




#### **FB Series Control Stations**

With ø22 mm XW Series EMO Switches





#### **FB Series Control Stations**

With ø22 mm XW Series EMO Switches + SEMI Switch Guard (HW9Z-KG4)









APEM Switches & Pilot Lights Control Boxe Emergency Stop Switches Enabling Switches Safety Products Explosion Proof Terminal Blocks

Relays & Sockets 166 Circuit Protectors

Power Supplies


**Control Boxes** 

LED Illumination

Controllers


Operator Interfaces

Sensors AUTO-ID




**FB Series Control Stations** With ø22 mm XW Series EMO Switches +


SEMI Switch Guard (HW9Z-KG3)



#### **Internal Dimensions**



# Base



APEM

## Switch/Pilot Light Mounting Hole Centers

Model	76mm	140	mm	200mm			
Mo	7011111	2 mounting holes	3 mounting holes	3 mounting holes	4 mounting holes	5 mounting holes	
Shape							


## Switches & Pilot Lights Emergency Stop Switches Enabling Switche Safety Products Explosion Proof Terminal Blocks Relays & Sockets Circuit Protectors Power Supplies LED Illumination Controllers

**Applicable Accessories** 

o Switches	Applicable Accessories					
Enabling	Series	Description				
Switches y Products		Nameplate: HWAM, HWAQ, HWAS, HWAV-□				
osion Proof		Marking plate for nameplate: HWNP-□				
inal Blocks		Anti-rotation ring: HW9Z-RL				
& Sockets	HW Series	EMO switch guard: HW9Z-KG3, HW9Z-KG4				
Circuit Protectors		Switch guard: HW9Z-K1, HW9Z-K11				
er Supplies		Pushbutton clear boot:				
lumination		0C-31, 0C-32				
Controllers		Padlock cover: HW9Z-KL1				
Operator Interfaces	XW Series	Nameplate: HWAV-□				
Sensors	Emergency Stop Switches	EMO switch guard: HW9Z-KG3, HW9Z-KG4				
AUTO-ID	Stop Switches	Anti-rotation ring: HW9Z-RL				
		Nameplate: NWA-□, NWAQ-□, NWAS-0, NWAL-0, NWAQL-0, NWAV-□				
FB		Anti-rotation ring: OGL-31				
	TW Series	Metal protector: OLW-C				
		Pushbutton clear boot: 0C-31, 0C-32				
		Button cover: OCW-10*, OCW-11*				
		Padlock cover: HW9Z-KL1, HS9Z-PC22				

Note: Confirm the specifications of boxes, switches/pilot lights, and accessories before choosing accessories, referring to separate catalogs.

## **Mounting Hole Dimensions**



Note: For contact cover boxes, see C-019.

#### **Applicable DIN Rail**

Description Material		Part No.	Ordering No.		
DIN Rail	Aluminum	BAA1000	BAA1000PN10		
	Steel	BAP1000	BAP1000PN10		
End Clip	Steel	BNL6	BNL6PN10		

Note: Use DIN rail adapters FB9Z-PK3 when installing a DIN in the control box. See H-071 for DIN rail products.

### **Applicable Terminal Block / Transformer**

	Series / Part No.
Terminal Block	BN-W / BNH-W / BN1U BN10W, BN15MW, BN15LW, BN30W BNH10W, BNH15MW, BNH15LW, BNH30W BN1U-16W, BN1U-20W, BN1U-40W
	BA BA111T, BA211T, BA311T
Separate Mountin TWR5**	g Transformer

Note: Install the terminal blocks and separate mounting transformers on a DIN rail using two DIN rail adapters (FB9Z-PK3). Choose the types and quantity of terminal blocks, transformers, end clips, and enclosures carefully taking the specifications into consideration. The separate mounting transformer can be installed on a DIN rail adapter directly.

# **Control Boxes**

APEM

Switches & Pilot Lights

Control Boxes
Emergency Stop Switches
Enabling Switches
Safety Products
Explosion Proof
Terminal Blocks

Relays & Sockets

## 1 Hole (Box Size: 76mm)

**Control Stations** 

Symbols of Switches

Item

**Emergency Stop Switches** 

Pushbuttons

Pilot Lights

Selector Switches

**Key Selector Switches** 

Symbols

(ES)

PB

(PL)

S

Symbols	Specification		Legend	<without nameplate=""></without>		With nameplate "EMERGENCY STOP		Protectors
		Switch Part No.	Contact Configuration	Part No. (Ordering Part No.)	Color (*)	Part No. (Ordering Part No.)	Color (*)	Power Supplies
			1NC	FB1W-XW1E-BV401MRH-Y0		FB1W-XW1E-BV401MRH-Y1		LED Illuminatio
			2NC	FB1W-XW1E-BV402MRH-Y0		FB1W-XW1E-BV402MRH-Y1		Operator
	XW Series Emergency Stop		3NC	FB1W-XW1E-BV403MRH-Y0		FB1W-XW1E-BV403MRH-Y1		Sensors
	Switches (Non-illuminated, pushlock pull or turn reset)		4NC	FB1W-XW1E-BV404MRH-Y0	- 	FB1W-XW1E-BV404MRH-Y1	1	AUTO-ID
		XW1E-BV4	1NO1NC	FB1W-XW1E-BV411MRH-Y0	- RH	FB1W-XW1E-BV411MRH-Y1	- RH	
			1N02NC	FB1W-XW1E-BV412MRH-Y0		FB1W-XW1E-BV412MRH-Y1		FB
			1NO3NC	FB1W-XW1E-BV413MRH-Y0		FB1W-XW1E-BV413MRH-Y1		-
			2N02NC	FB1W-XW1E-BV422MRH-Y0		FB1W-XW1E-BV422MRH-Y1		
ES		nated LED/24V	1NC	FB1W-XW1E-LV401Q4MR-Y0	-	FB1W-XW1E-LV401Q4MR-Y1		
			2NC	FB1W-XW1E-LV402Q4MR-Y0		FB1W-XW1E-LV402Q4MR-Y1		
			3NC	FB1W-XW1E-LV403Q4MR-Y00		FB1W-XW1E-LV403Q4MR-Y1		
	XW Series Emergency Stop Switches (Illuminated, LED/24V,		4NC	FB1W-XW1E-LV404Q4MR-Y0		FB1W-XW1E-LV404Q4MR-Y1		
	pushlock pull or turn reset)	XW1E-LV4	1N01NC	FB1W-XW1E-LV411Q4MR-Y0	- R	FB1W-XW1E-LV411Q4MR-Y1	- R	
			1N02NC	FB1W-XW1E-LV412Q4MR-Y0		FB1W-XW1E-LV412Q4MR-Y1		
			1NO3NC	FB1W-XW1E-LV413Q4MR-Y0	1	FB1W-XW1E-LV413Q4MR-Y1	1	
			2N02NC	FB1W-XW1E-LV422Q4MR-Y0	1	FB1W-XW1E-LV422Q4MR-Y1	]	
	XW Series Emergency Stop Switches		3NC	FB1W-XW1E-TV403Q4MR-Y0	P	FB1W-XW1E-TV403Q4MR-Y1		
	(Push-ON LED, LED/24V,pushlock pull or turn reset)	XW1E-TV4	1N02NC	FB1W-XW1E-TV412Q4MR-Y0	– R	FB1W-XW1E-TV412Q4MR-Y1	- R	

Color code (\*): Red (R), Bright Red (RH)

## Legend / Guard

Le	gend / Guard	Nameplate Part No.	Guard / Marking Plate Part No.	
	<optional marking="" plate=""></optional>	HWAM	-	
E-STOP Nameplate	<yellow -="" blank=""></yellow>	HWAV-0	-	
Namoplato	EMERGENCY-STOP	HWAV-27	-	
	ON	HWAM	HWNP-1	
	0FF	HWAM	HWNP-2	
	START	HWAM	HWNP-3	
Nameplate	STOP	HWAM	HWNP-4	
	OFF-ON	HWAM	HWNP-31	
	HAND-AUTO	HWAM	HWNP-35	
	HAND-OFF-AUTO	HWAM	HWNP-53	
Quand	HW9Z-KG4	-	HW9Z-KG4	
Guard	HW9Z-KG3	-	HW9Z-KG3	

📩 Download catalogs and CAD from http://asia.idec.com/downloads

#### **Control Stations**

**Control Boxes** 

Controllers

#### 1 Hole (Box Size: 76mm)

S.												
	Symbol	Specification		Legend	<without nameplate=""></without>		With nameplate "EMERGENCY"stop					
			Switch Part No.	Contact Configuration	Part No. (Ordering Part No.)	Color (*)	Part No. (Ordering Part No.)	Color (*)				
APEM		HW Series Emergency Stop Switches		1NC	FB1W-HW1B-V401R-Y0		FB1W-HW1B-V401R-Y1					
Switches & Pilot Lights		(Pushlock turn reset)	HW1B-V4	2NC	FB1W-HW1B-V402R-Y0	R	FB1W-HW1B-V402R-Y1	R				
Control Boxes				1N01NC	FB1W-HW1B-V411R-Y0		FB1W-HW1B-V411R-Y1					
Emergency Stop Switches Enabling		HW Series Emergency Stop Switches		1NC	FB1W-HW1B-Y201R-Y0		FB1W-HW1B-Y201R-Y1					
Switches Safety Products	ES		HW1B-Y2	2NC	FB1W-HW1B-Y202R-Y0	R	FB1W-HW1B-Y202R-Y1	R				
Explosion Proof		(Pushlock pull reset)	niock pull reset)	1N01NC	FB1W-HW1B-Y211R-Y0		FB1W-HW1B-Y211R-Y1					
Terminal Blocks				1NC	FB1W-HW1B-X401R-Y0		FB1W-HW1B-X401R-Y1					
Relays & Sockets		HW Series Emergency Stop Switches (Pushlock key reset)	HW1B-X4	2NC	FB1W-HW1B-X402R-Y0	R	FB1W-HW1B-X402R-Y1	R				
Circuit Protectors				1N01NC	FB1W-HW1B-X411R-Y0		FB1W-HW1B-X411R-Y1					
Power Supplies	Color code (*)	· Bed (B)	<u> </u>	1								

Color code (\*): Red (R) LED Illumination

## Control Stations with SEMI Emergency off (EMO) Switches

Operator Interfaces	Symbol	Specification		Guard	<without guard=""></without>		SEMI Switchguard		
Sensors			Switch Part No.	Contact Configuration	Part No. (Ordering Part No.)	Color (*)	Part No. (Ordering Part No.)	Color (*)	
AUTO-ID		HW Series SEMI EMO Pushbutton (Pushlock turn reset)			1NC	FB1W-HW1B-V401R-EMO-Y0		FB1W-HW1B-V401R-EM0-Y□	
			HW1B-V4	2NC	FB1W-HW1B-V402R-EMO-Y0	R	FB1W-HW1B-V402R-EM0-Y□	R	
FB				1NO1NC	FB1W-HW1B-V411R-EMO-Y0		FB1W-HW1B-V411R-EMO-Y□		
				1NC	FB1W-XW1E-BV401MRH-EM0-Y0		FB1W-XW1E-BV401MRH-EM0-Y□		
	ES			2NC	FB1W-XW1E-BV402MRH-EM0-Y0		FB1W-XW1E-BV402MRH-EM0-Y□		
	(For SEMI)			3NC	FB1W-XW1E-BV403MRH-EM0-Y0		FB1W-XW1E-BV403MRH-EM0-Y		
		XW Series SEMI EMO Pushbuttons	XW1E-BV4	4NC	FB1W-XW1E-BV404MRH-EM0-Y0	RH	FB1W-XW1E-BV404MRH-EM0-Y	RH	
		(Non-illuminated, pushlock pull or turn reset)	AWIL-DV4	1N01NC	FB1W-XW1E-BV411MRH-EMO-Y0	nii	FB1W-XW1E-BV411MRH-EMO-Y		
			-	1NO2NC	FB1W-XW1E-BV412MRH-EMO-Y0		FB1W-XW1E-BV412MRH-EMO-Y	-	
				1NO3NC	FB1W-XW1E-BV413MRH-EMO-Y0		FB1W-XW1E-BV413MRH-EMO-Y□		
				2N02NC	FB1W-XW1E-BV422MRH-EM0-Y0		FB1W-XW1E-BV422MRH-EM0-Y□		

Color code (\*): Red (R), Bright Red (RH)

\*1) Specify a code for SEMI switchguard in place of 🗖 in the part no. (2: HW9Z-KG3, 3: HW9Z-KG4) Control stations with HW9Z-KG3, HW9Z-KG4 are SEMI S2 compliant. For details, see D-052.

#### **Control Stations**













With HW1B-V4

With HW1B-V4 & HW9Z-KG3

With HW1B-V4 & HW9Z-KG4

With XW1E-BV4

With XW1E-BV4 & HW9Z-KG3

With XW1E-BV4 & HW9Z-KG4

For more information, visit http://asia.idec.com

**Control Boxes** 

Terminal Blocks Relays & Sockets

## **Control Stations**

## 1 Hole (Box Size: 76mm)

Specification		Legend	<without nameplate=""></without>		<optional marking="" plate=""></optional>		
	Switch Part No.	Contact Configuration	Part No. (Ordering Part No.)	Color (*)	Part No. (Ordering Part No.)	Color (*)	
Pushbutton (Momentary,flush)		1N0	FB1W-HW1B-M110*-Z0	G	FB1W-HW1B-M110*-Z1	G	APEM
	HW1B-M1	1N01NC	FB1W-HW1B-M111*-Z0	Ŵ	FB1W-HW1B-M111*-Z1	Ŵ	Switches & Pilot Lights
	HW1B-M2	1NC	FR1W-HW1R-M201*-70		FR1W-HW1R-M201*-71	R	Control Boxes
Pushbutton				R			Emergency Stop Switches
(Momentary, extended)		1N01NC	FB1W-HW1B-M211*-Z0	Б	FB1W-HW1B-M211*-Z1	Б	Enabling Switches
Pushbutton	HW1B-M4	1N0	FB1W-HW1B-M410*-Z0		FB1W-HW1B-M410G-Z1 FB1W-HW1B-M411G-Z1		Safety Products
(Momentary, ø40)		1N01NC	FB1W-HW1B-M411G-Z0	6			Explosion Proof
	Pushbutton (Momentary,flush) Pushbutton (Momentary, extended) Pushbutton	Pushbutton (Momentary,flush) Pushbutton (Momentary,flush) HW1B-M1 HW1B-M2 Pushbutton HW1B-M4	Switch Part No.     Contact Configuration       Pushbutton (Momentary,flush)     HW1B-M1     1N0       Pushbutton (Momentary, extended)     HW1B-M2     1NC       Pushbutton (Momentary, extended)     1N01NC       Pushbutton (Momentary, e40)     HW1B-M4	Pushbutton (Momentary,flush)     Switch Part No.     Contact Configuration     Part No. (Ordering Part No.)       Pushbutton (Momentary,flush)     HW1B-M1     1N0     FB1W-HW1B-M110*-Z0       Pushbutton (Momentary, extended)     HW1B-M2     1NC     FB1W-HW1B-M111*-Z0       Pushbutton (Momentary, extended)     HW1B-M2     1NC     FB1W-HW1B-M201*-Z0       Pushbutton (Momentary, extended)     HW1B-M4     1N0     FB1W-HW1B-M211*-Z0	Switch Part No.         Contact Configuration         Part No. (Ordering Part No.)         Color (*)           Pushbutton (Momentary,flush)         HW1B-M1         1N0         FB1W-HW1B-M110*-Z0         G W           Pushbutton (Momentary, extended)         HW1B-M2         1NC         FB1W-HW1B-M201*-Z0         R B           Pushbutton (Momentary, extended)         HW1B-M2         1NC         FB1W-HW1B-M201*-Z0         R G           Pushbutton (Momentary, extended)         HW1B-M4         1N0         FB1W-HW1B-M410*-Z0         G	Pushbutton (Momentary,flush)Switch Part No.Contact ConfigurationPart No. (Ordering Part No.)Color (*)Part No. (Ordering Part No.)Pushbutton (Momentary,flush) $HW1B-M1$ $1NO$ $FB1W-HW1B-M110*-ZO$ $1NO1NC$ $GW$ $FB1W-HW1B-M110*-Z1$ Pushbutton (Momentary, extended) $HW1B-M2$ $1NC$ $FB1W-HW1B-M201*-ZO$ $1NO1NC$ $BW1B-M201*-Z0$ $FB1W-HW1B-M201*-ZO$ $BW$ Pushbutton (Momentary, extended) $HW1B-M2$ $1NC$ $FB1W-HW1B-M201*-Z0$ $FB1W-HW1B-M211*-ZO$ $BW$ Pushbutton (Momentary, extended) $HW1B-M4$ $1NO$ $FB1W-HW1B-M211*-Z0$ $BW$ Pushbutton (Momentary, extended) $HW1B-M4$ $1NO$ $FB1W-HW1B-M410*-Z0$ $GW$ $G$	Switch Part No.Contact ConfigurationPart No. (Ordering Part No.)Color (*)Part No. (Ordering Part No.)Color (*)Pushbutton (Momentary,flush) $HW1B-M1$ $1NO$ $FB1W-HW1B-M110*-ZO$ $1NO1NC$ $G$ $FB1W-HW1B-M111*-ZO$ $G$ $W$ $FB1W-HW1B-M110*-Z1$ $G$ $W$ $G$ $FB1W-HW1B-M111*-Z1$ $G$ $W$ Pushbutton (Momentary, extended) $HW1B-M2$ $1NC$ $FB1W-HW1B-M201*-ZO$ $INO1NC$ $R$ $B1W-HW1B-M201*-Z0$ $FB1W-HW1B-M201*-Z1$ $R$ $B$ $R$ $FB1W-HW1B-M201*-Z1$ $R$ $B$ Pushbutton (Momentary, extended) $HW1B-M4$ $1NO$ $FB1W-HW1B-M211*-Z0$ $R$ $B$ $FB1W-HW1B-M211*-Z1$ $R$ $B$ Pushbutton (Momentary, extended) $HW1B-M4$ $1NO$ $FB1W-HW1B-M410*-Z0$ $G$ $G$ $FB1W-HW1B-M410G-Z1$ $G$ $G$

Color code (\*): Black (B), Green (G), Red (R), White (W)

Symbol	Specification		Legend	With nameplate "ON"		With nameplate "START"		Circuit Protectors
		Switch Part No.	Contact Configuration	Part No. (Ordering Part No.)	Color (*)	Part No. (Ordering Part No.)	Color (*)	Power Supplies
	Pushbutton (Momentary,flush)	HW1B-M1	1N0	FB1W-HW1B-M110*-Z2		FB1W-HW1B-M110*-Z3		LED Illumination
					GW		GW	Controllers
PB			1NO1NC	FB1W-HW1B-M111*-Z2	vv		FB1W-HW1B-M111*-Z3	**
	Pushbutton (Momentary, ø40)	I HW18-M4	1N0	FB1W-HW1B-M410G-Z2		FB1W-HW1B-M410G-Z3	-	Sensors
			1N01NC	FB1W-HW1B-M411G-Z2	G	FB1W-HW1B-M411G-Z3	G	AUTO-ID
						101011010-004110-23		

Color code (\*): Green (G), White (W)

Symbol	Specification		Legend	With nameplate "OFF"		With nameplate "STOP"		
		Switch Part No.	Contact Configuration	Part No. (Ordering Part No.)	Color (*)	Part No. (Ordering Part No.)	Color (*)	
PB	Pushbutton (Momentary, extended)	HW1B-M2	1NC	FB1W-HW1B-M201*-Z2	R	FB1W-HW1B-M201*-Z3	R	]
			1N01NC	FB1W-HW1B-M211*-Z2	В	FB1W-HW1B-M211*-Z3	В	

Color code (\*): Black (B), Red (R)

Symbol	Specification		Legend		With "I&ON/0&OFF" on Switch		
			Contact Configuration		Part No. (Ordering Part No.)	Color (*)	
	Dual Pushbutton	Switch Part No.	Top Button	Bottom Buttton	r art no. (ordoning r art no.)		
PB	(Momentary, flush–extended)	HW7D-B12	1N0	1NC	FB1W-HW7D-B121001WB1-Z0	WB (Top: White / Bottom: Black)	
	Dual Pushbutton (Interlock, flush-extended)	HW/11-822		1NC	FB1W-HW7D-B221001WB1-Z0	WB (Top: White / Bottom: Black)	

Symbol	Specification		Legend	<without nameplate=""></without>					
		Switch Part No.	Illuminated Voltage	Part No. (Ordering Part No.)	Color (*)	Part No. (Ordering Part No.)	Color (*)		
PL	Pilot Light	HW1P-2Q (Round extended)	LED / 24V	FB1W-HW1P-2Q4*-Z0	Color 1	FB1W-HW1P-2Q4*-Z0	PW S		
		HW1P-5Q (Dome)	LED / 24V	FB1W-HW1P-5Q4*-Z0	Color 1	FB1W-HW1P-5Q4*-Z0	PW S		

(Color 1) R ,G, A, Y

Color code (\*): Red (R), Green (G), Amber (A), Yellow (Y), Pure White (PW), Blue (S)

## **Control Stations**

### 1 Hole (Box Size: 76mm)

Symbol	Symbol Specification		Legend	<without nameplate=""></without>	<optional marking="" plate=""></optional>
	Selector Switches	Switch Part No.	Contact Configuration	Part No. (Orde	aring Part No.)
	(2-position maintained, knob, black)	HW1S-2T	1N0	FB1W-HW1S-2T10-Z0	FB1W-HW1S-2T10-Z1
SS	,		1N01NC	FB1W-HW1S-2T11-Z0	FB1W-HW1S-2T11-Z1
	Selector Switches		1N0	FB1W-HW1K-2A10-Z0	FB1W-HW1K-2A10-Z1
	(2-position maintained, knob, key selector) (*1)	HW1K-2A	1N01NC	FB1W-HW1K-2A11-Z0	FB1W-HW1K-2A11-Z1

\*1) Keys removable in both left and right.

Explosion Floor							
Terminal Blocks	Symbol	Specification		Legend	With nameplate "ON-OFF"	With nameplate "HAND-AUTO"	
Relays & Sockets		Colorday Cuitabaa	Switch Part No.	Contact Part No. (Ordering Part No.)			
Circuit Protectors		Selector Switches (2-position maintained, knob, black)	HW1S-2T	1N0	FB1W-HW1S-2T10-Z2	FB1W-HW1S-2T10-Z3	
Power Supplies	SS			1N01NC	FB1W-HW1S-2T11-Z2	FB1W-HW1S-2T11-Z3	
LED Illumination		Selector Switches		1N0	FB1W-HW1K-2A10-Z2	FB1W-HW1K-2A10-Z3	
Controllers		(2-position maintained, knob, key selector) (*1)	HW1K-2A	1N01NC	FB1W-HW1K-2A11-Z2	FB1W-HW1K-2A11-Z3	
Operator Interfaces		voble in both left and right		INCINC		T DTW-TWTR-ZATT-25	

\*1) Keys removable in both left and right.

Symbol	Specification		Legend	<without nameplate=""></without>	<optional marking="" plate=""></optional>	
	Selector Switches (3-position maintained, knob, black)         Switch Part No.         Contact Configuration           HW1S-3T         2N0		Contact Configuration	Part No. (Ordering Part No.)		
			2N0	FB1W-HW1S-3T20-Z0	FB1W-HW1S-3T20-Z1	

Symbol	Specification		Legend	With nameplate "HAND-OFF-AUTO"
(SS)	Selector Switches (3-position maintained, knob,	Switch Part No.	Contact Configuration	Part No. (Ordering Part No.)
	black)	HW1S-3T	2N0	FB1W-HW1S-3T20-Z2

## 2 Holes (Box Size: 140mm, Mounting Centers: 50mm)

Symbol	Specification		Legend ①	<without nameplate=""></without>	<optional marking="" plate=""></optional>	With nameplate "ON"	With nameplate "START"			
Symbol			Legend 2	<without nameplate=""></without>	<optional marking="" plate=""></optional>	With nameplate "OFF"	With nameplate "STOP"			
0 <b>PB</b>	<ul> <li>①Pushbutton (Momentary, flush, green)</li> <li>②Pushbutton (Momentary, flush, red)</li> </ul>	Switch Part No.	Contact Configuration		Part No. (Ordering Part No.)					
		HW1B-M1 HW1B-M1	1N0 1N0	FB2W-211Z-A02001	-	-	-			
2 <b>PB</b>			1N0 1NC	FB2W-211Z-A02002	FB2W-211Z-A02003	FB2W-211Z-A02004	FB2W-211Z-A02005			
			1N01NC 1N01NC	FB2W-211Z-A02006	FB2W-211Z-A02007	FB2W-211Z-A02008	FB2W-211Z-A02009			

Cumbol	Symbol		Legend	<without nameplate=""></without>	<0ptional marking plate>	With nameplate "ON"	With nameplate "START"			
Symbol	Specification		Legend@	<without nameplate=""></without>	<optional marking="" plate=""></optional>	With nameplate "OFF"	With nameplate "STOP"			
	<ul> <li>①Pushbutton</li> <li>(Momentary, flush, white)</li> </ul>	Switch Part No.	Contact Configuration		Part No. (Ordering Part No.)					
		HW1B-M1 HW1B-M1	1N0 1N0	FB2W-211Z-A02010	-	_	-			
© (PB)	②Pushbutton (Momentary, flush, black)		1N0 1NC	FB2W-211Z-A02011	FB2W-211Z-A02012	FB2W-211Z-A02013	FB2W-211Z-A02014			
			1N01NC 1N01NC	FB2W-211Z-A02015	FB2W-211Z-A02016	FB2W-211Z-A02017	FB2W-211Z-A02018			

## For more information, visit http://asia.idec.com

Safety Products Explosion Proof Terminal Block Relays & Socke Circu Protector

> Sensors AUTO-ID

APEM Switches & Pilot Lights

Emergency Stop Switches Enabling Switches

## **Control Stations**

## 2 Holes (Box Size: 140mm, Mounting Centers: 50mm)

		<b>`</b>	· J		,				
ſ	Symbol	Specification	$\backslash$	Legend ①	<without nameplate=""></without>	<optional marking="" plate=""></optional>	With nameplate "ON"	With nameplate "START"	
	Symbol	opecification		Legend@	<without nameplate=""></without>	<optional marking="" plate=""></optional>	With nameplate "OFF"	With nameplate "STOP"	
		/ (womentary, nuon, green)		Contact		Part No. (Orde	ering Part No.)		
	$\square$			Configuration	Iguration				
			HW1B-M1	1N0 1NC	FB2W-211Z-A02019	FB2W-211Z-A02020	FB2W-211Z-A02021	FB2W-211Z-A02022	APEM
	© (PB)	(Momentary, extended, red)		-					Switches &
		(monitoritary, externed, red)	HW1B-M2	1N01NC 1N01NC	FB2W-211Z-A02023	FB2W-211Z-A02024	FB2W-211Z-A02025	FB2W-211Z-A02026	Pilot Lights
				INUTING					

								Emergency Stop Switches	
Symbol	Specification		Legend	<without nameplate=""></without>	<optional marking="" plate=""></optional>	With nameplate "ON"	With nameplate "START"	Enabling	
Symbol	Specification		Legend@	<without nameplate=""></without>	<optional marking="" plate=""></optional>	With nameplate "OFF"	With nameplate "STOP"	Switches	
	<ul> <li>①Pushbutton (Momentary, flush, white)</li> <li>②Pushbutton (Momentary, extended, red)</li> </ul>		Contact Configuration		Part No. (Ordering Part No.)				
		HW1B-M1	1N0 1NC	FB2W-211Z-A02027	FB2W-211Z-A02028	FB2W-211Z-A02029	FB2W-211Z-A02030	Explosion Proof	
2 (PB)		HW1B-M2	1N01NC	FB2W-211Z-A02031	FB2W-211Z-A02032	FB2W-211Z-A02033	FB2W-211Z-A02034	Terminal Blocks	
			1N01NC	1 DZW-2112-A02031	1 DZW-2112-A02032	1 DZW-2112-A02033	1 DZW-2112-A02034	Relays & Sockets	

ĺ				Legend	<without nameplate=""></without>	<0ptional marking plate>	With nameplate "ON"	With nameplate "START"	Circuit Protectors
	Symbol	Specification		Legend@	<without nameplate=""></without>	<0ptional marking plate>	With nameplate "OFF"	With nameplate "STOP"	Power Supplies
			Switch Part No.	Contact Configuration		Part No. (Orde	ring Part No.)		LED Illumination
	0 PB 2 PB	<ul> <li>①Pushbutton (Momentary, flush, white)</li> <li>②Pushbutton</li> </ul>	white) 11 HW1B-M1 11	1NO					
				1NC	FB2W-211Z-A02035	FB2W-211Z-A02036	FB2W-211Z-A02037	FB2W-211Z-A02038	Controllers
		(Momentary, ø40, black)	HW1B-M4	1N01NC 1N01NC	FB2W-211Z-A02039	FB2W-211Z-A02040	FB2W-211Z-A02041	FB2W-211Z-A02042	Operator Interfaces

Symbol	Specification		Legend ①	<without nameplate=""></without>
Symbol	Specification		Legend@	<without nameplate=""></without>
0 PL	①Pilot Light (Round extended, red)	Switch Part No.	Illuminated Voltage	Part No. (Ordering Part No.)
2 PL	②Pilot Light (Round extended, green)	HW1P-2Q HW1P-2Q	LED / 24V LED / 24V	FB2W-211Z-A02043

Symbol	Specification		Legend ①	<without nameplate=""></without>	<without nameplate=""></without>	<without nameplate=""></without>
Symbol	opeemeation		Legend@	<without nameplate=""></without>	<optional marking="" plate=""></optional>	With nameplate "STOP"
0 PL	①Pilot Light (Round extended, red)	Switch Part No.	Illuminated Voltage Contact Configuration		Part No. (Ordering Part No.)	
2 <b>PB</b>	②Pilot Light (Momentary, extended,black)	HW1P-2Q HW1B-M2	LED / 24V 1N01NC	FB2W-211Z-A02045	FB2W-211Z-A02046	FB2W-211Z-A02047

Symbol	Specification		Legend	<without nameplate=""></without>	<without nameplate=""></without>	
Symbol			Legend@	<without nameplate=""></without>	<optional marking="" plate=""></optional>	With nameplate "HAND-AUTO"
	①Pilot Light (Round extended, red)	Switch Part No.	Illuminated Voltage Contact Configuration			
0 ŠŠ	©Selector Switch (2-position maintained, knob, black)	HW1P-2Q HW1S-2T	LED / 24V 1N01NC	FB2W-211Z-A02048	FB2W-211Z-A02049	FB2W-211Z-A02050

Symbol	Specification		Legend	<without nameplate=""> <without nameplate=""> <without name<="" th=""></without></without></without>		
Symbol			Legend@	<without nameplate=""></without>	<0ptional marking plate>	With nameplate "HAND-AUTO"
0 PL	①Pilot Light (Round extended, red)	Switch Part No.	Illuminated Voltage Contact Configuration			
2 <u>S</u>	© Selector Switch (*1) (2-position maintained, key selector)	HW1P-2Q HW1K-2A	LED / 24V 1N01NC	FB2W-211Z-A02051	FB2W-211Z-A02052	FB2W-211Z-A02053

 $^{\ast}$  1) Keys removable in both left and right.

**Control Boxes** 

## **Control Stations**

## 3 Holes (Box Size: 140mm, Mounting Centers: 30mm)

	Symbol Specification		Legend ①	<without nameplate=""></without>	<optional marking="" plate=""></optional>	
	Symbol Specification		Legend	<without nameplate=""></without>	<optional marking="" plate=""></optional>	
	0 2 3		Legend 3	<without nameplate=""></without>	<optional marking="" plate=""></optional>	
APEM	PBPBPB	Switch Part No.	Contact Configuration	Part No. (Ordering Part No.)		
Switches & Pilot Lights	<ul> <li>①Pushbutton (Momentary, flush, green)</li> <li>②Pushbutton (Momentary, flush, red)</li> <li>③Pushbutton (Momentary, flush, green)</li> </ul>	HW1B-M1 HW1B-M1 HW1B-M1	1NO 1NC 1NO	FB2W-312Z-A03001	FB2W-312Z-A03002	
Control Boxes						

Emergency						
Stop Switches	Symbol Specification		Legend	<without nameplate=""></without>	<optional marking="" plate=""></optional>	
Enabling	Symbol Specification		Legend	<without nameplate=""></without>	<optional marking="" plate=""></optional>	
Switches	0 2 3		Legend 3	<without nameplate=""></without>	<optional marking="" plate=""></optional>	
Safety Products	PBPBPB	Switch Part No.	Contact Configuration	Part No. (Ordering Part No.)		
Explosion Proof	①Pushbutton (Momentary, flush, white)	HW1B-M1	1N0			
Terminal Blocks	<ul> <li>②Pushbutton (Momentary, flush, red)</li> <li>③Pushbutton (Momentary, flush, black)</li> </ul>	HW1B-M1 HW1B-M1	1NC 1NO	FB2W-312Z-A03003	FB2W-312Z-A03004	

Circuit	Symbol Specification		Legend <sup>①</sup>	<without nameplate=""></without>	<without nameplate=""></without>	<without nameplate=""></without>	<without nameplate=""></without>	
Protectors	Symbol Specification		Legend	<without nameplate=""></without>	<optional marking="" plate=""></optional>	With nameplate "ON"	With nameplate "START"	
Power Supplies	0 2 3		Legend3	<without nameplate=""></without>	<optional marking="" plate=""></optional>	With nameplate "OFF"	With nameplate "STOP"	
	(PL)(PB)(PB)	Switch Part No.	Illuminated Voltage		ring Part No.)			
LED Illumination	FUFBIFB	Switch Fart No.	Contact Configuration	Part No. (Ordering Part No.)				
0	①Pilot Light (Round extended, red)	HW1P-2Q	LED / 24V					
Controllers	②Pushbutton (Momentary, flush, red)	HW1B-M1	1N0	FB2W-312Z-A03005	FB2W-312Z-A03006	FB2W-312Z-A03007	FB2W-312Z-A03008	
Operator	③Pushbutton (Momentary, extended, black)	HW1B-M2	1NC					
Interfaces								

#### Sensors 3 Holes (Box Size: 200mm, Mounting Centers: 50mm) AUTO-ID

Symbol	Specification	$\geq$	Legend ①	<without nameplate=""></without>	<optional marking="" plate=""></optional>
Symbol	opecification		Legend	<without nameplate=""></without>	<optional marking="" plate=""></optional>
			Legend3	<without nameplate=""></without>	<optional marking="" plate=""></optional>
0 <b>PB</b>	①Pushbutton	Switch Part No.	Contact Configuration	Part No. (Ord	ering Part No.)
© PB © PB © B	(Momentary, flush, green) ©Pushbutton (Momentary, flush, red) ③Pushbutton	HW1B-M1 HW1B-M1	1NO 1NC 1NO	FB3W-311Z-A03009	FB3W-311Z-A03010
	(Momentary, flush, green)	HW1B-M1	1N01NC 1N01NC 1N01NC	FB3W-311Z-A03011	FB3W-311Z-A03012

Symbol	Constitution		Legend ①	<without nameplate=""></without>	<0ptional marking plate>
Symbol	Specification		Legend	<without nameplate=""></without>	<optional marking="" plate=""></optional>
			Legend3	<without nameplate=""></without>	<optional marking="" plate=""></optional>
0 PB	①Pushbutton	Switch Part No.	Contact Configuration	Part No. (Ordering Part No.)	
© PB © PB © PB	(Momentary, flush, white) ②Pushbutton (Momentary, flush, red) ③Pushbutton (Momentary, flush, black)	HW1B-M1 HW1B-M1	1N0 1NC 1N0	FB3W-311Z-A03013	FB3W-311Z-A03014
		HW1B-M1	1N01NC 1N01NC 1N01NC	FB3W-311Z-A03015	FB3W-311Z-A03016

Γ	Symbol	Specification	$\smallsetminus$	Legend ①	<without nameplate=""></without>	With nameplate "ON"	With nameplate "START"
	Symbol	Specification		Legend	<without nameplate=""></without>	With nameplate "OFF"	With nameplate "STOP"
		© Duahhuttaa		Legend3	<none> (with yellow blank nameplate)</none>	With nameplate"EMERGENCY-STOP"	With nameplate"EMERGENCY-STOP"
		(Momentary, flush, white)	Switch Part No.	Contact Configuration		Part No. (Ordering Part No.)	
		<ul> <li>②PUSNDUTION (Momentary, flush, black)</li> <li>③Emergency Stop Switch (Pushlock turn reset)</li> </ul>	HW1B-M1 HW1B-M2 HW1B-V4	1N0 1NC 2NC	FB3W-311Z-A03017	FB3W-311Z-A03018	FB3W-311Z-A03019

Relays & Sockets

## **Control Stations**

## 3 Holes (Box Size: 140mm, Mounting Centers: 30mm)

Symbol	ol Specification		Legend (1)	<without nameplate=""></without>	With nameplate "ON"	With nameplate "START"
Symbol			Legend	<without nameplate=""></without>	With nameplate "OFF"	With nameplate "STOP"
			Legend3	<none> (with yellow blank nameplate)</none>	With nameplate "EMERGENCY-STOP"	With nameplate"EMERGENCY-STOP"
①     (PB)     (Mom       ②     (PB)     (Mom       ②     (Mom       (Mom	①Pushbutton	Switch Part No.	Contact Configuration	Part No. (Ordering Part No.)		
	(Momentary, flush, white) ②Pushbutton (Momentary, extended, black) ③ Emergency Stop Switch	HW1B-M1 HW1B-M2	1N01NC 1N01NC 2NC	FB3W-311Z-A03020	FB3W-311Z-A03021	FB3W-311Z-A03022
3 (ES)	(Pushlock pull or turn reset)	XW1E-BV4	1N01NC 1N01NC 1N02NC	FB3W-311Z-A03026	FB3W-311Z-A03027	FB3W-311Z-A03028

Symbol	Specification		Legend	<without nameplate=""></without>	With nameplate "ON"	With nameplate "START"
Symbol	opecification		Legend	<without nameplate=""></without>	With nameplate "OFF"	With nameplate "STOP"
			Legend3	<none> (with yellow blank nameplate)</none>	With nameplate"EMERGENCY-STOP"	With nameplate"EMERGENCY-STOP"
2 Pushbutton (Momentary, exter 3 Emergency Stop	①Pushbutton (Momentary, flush, white)	Switch Part No.	Illuminated Voltage Contact Configuration		Part No. (Ordering Part No.)	
		HW1B-M1 HW1B-M2	2NC/LED/24V 1N01NC 1N01NC	FB3W-311Z-A03023	FB3W-311Z-A03024	FB3W-311Z-A03025
3 (ES)		XW1E-LV4	1NO2NC/LED/24V 1NO1NC 1NO1NC	FB3W-311Z-A03029	FB3W-311Z-A03030	FB3W-311Z-A03031

Symbol	Symbol Specification		Legend ①	<without nameplate=""></without>	<without nameplate=""></without>	<without nameplate=""></without>	<without nameplate=""></without>	Contro
Symbol	Specification		Legend	<without nameplate=""></without>	<optional marking="" plate=""></optional>	With nameplate "ON"	With nameplate "START"	Operat
			Legend3	<without nameplate=""></without>	<optional marking="" plate=""></optional>	With nameplate "OFF"	With nameplate "STOP"	Interfa
	© Pilot Light	Switch Part No.	Illuminated Voltage Contact Configuration		Part No. (Orde	ering Part No.)		Senso
<ul> <li>(Round extended, red</li> <li>(Round extended, red</li> <li>(PB)</li> <li>(Pushbutton</li> <li>(Momentary, flush, w</li> <li>(Pushbutton)</li> </ul>	(Momentary, flush, white)	HW1P-2Q HW1B-M1	LED / 24V 1N0 1NC	FB3W-311Z-A03032	FB3W-311Z-A03033	FB3W-311Z-A03034	FB3W-311Z-A03035	AUTO-
	(Momentary, extended, black)	HW1B-M1	LED / 24V 1N01NC 1N01NC	FB3W-311Z-A03036	FB3W-311Z-A03037	FB3W-311Z-A03038	FB3W-311Z-A03039	FB

Symbol	Specification		Legend ①	<without nameplate=""></without>	<0ptional marking plate>	With nameplate "ON"	With nameplate "START"
Symbol	Specification		Legend@	<without nameplate=""></without>	<optional marking="" plate=""></optional>	With nameplate "OFF"	With nameplate "STOP"
			Legend3	<without nameplate=""></without>	<0ptional marking plate>	With nameplate "HAND-AUTO"	With nameplate "HAND-AUTO"
	<ul> <li>PB</li> <li>PB</li> <li>PB</li> <li>PB</li> <li>SS</li> <li>Pushbutton (Momentary, flush, white)</li> <li>Pushbutton</li> <li>Pushbutton</li> <li>Momentary, flush, black)</li> <li>Selector Switch</li> <li>(2-position, knob, black)</li> </ul>	Switch Part No.	Contact Configuration		Part No. (Orde	ering Part No.)	
		HW1B-M1	1NO 1NC 1NO	FB3W-311Z-A03041	FB3W-311Z-A03042	FB3W-311Z-A03044	FB3W-311Z-A03043
		HW1B-M2 HW1S-2T	1N01NC 1N01NC 1N01NC	FB3W-311Z-A03045	FB3W-311Z-A03046	FB3W-311Z-A03048	FB3W-311Z-A03047

**Control Boxes** 

#### APEM

Switches & Pilot Lights

Emergency Stop Switches

Enabling Switches

Safety Products

Explosion Proof

Terminal Blocks

Relays & Sockets

Circuit Protectors Power Supplies

LED Illumination

Controllers
Operator nterfaces
Sensors
AUTO-ID

#### **Control Stations**

## 4 Holes (Box Size: 200mm, Mounting Centers: 36mm)

	Symbol Specification		Legend	<without nameplate=""></without>	<without nameplate=""></without>	<without nameplate=""></without>
	Symbol Specification		Legend@	<without nameplate=""></without>	<without nameplate=""></without>	<without nameplate=""></without>
			Legend3	<without nameplate=""></without>	<optional marking="" plate=""></optional>	With nameplate "ON"
	0 2 3 4		Legend ④	<without nameplate=""></without>	<optional marking="" plate=""></optional>	With nameplate "OFF"
APEM	PLPLPBPB	Switch Part No.	Illuminated Voltage Contact Configuration	Part No. (Ordering Part No.)		
Switches & Pilot Lights	①Pilot Light (Round extended, red)	HW1P-2Q	LED / 24V			
	DPilot Light (Round extended, red)     Pilot Light (Round extended, green)     Pushbutton (Momentary, flush, white)     OPushbutton (Momentary, extended, black)	HW1P-2Q HW1P-2Q HW1B-M1 HW1B-M2	-	FB3W-413Z-A04001	FB3W-413Z-A04002	FB3W-413Z-A04003
			LED / 24V			

Enabling						
Switches	Symbol Specification	$\searrow$	Legend	<without nameplate=""></without>	<without nameplate=""></without>	<without nameplate=""></without>
	Symbol Specification		Legend@	<without nameplate=""></without>	<optional marking="" plate=""></optional>	With nameplate "ON"
Safety Products	(1) (2) (3) (A)		Legend3	<without nameplate=""></without>	<optional marking="" plate=""></optional>	With nameplate "OFF"
Explosion Proof	PUPBPBSS		Legend@	<without nameplate=""></without>	<0ptional marking plate>	With nameplate "HAND-AUTO"
Explosion room		Switch Part No.	Illuminated Voltage		Part No. (Ordering Part No.)	
Terminal Blocks		SWILLII FAIL NU.	Contact Configuration		rait No. (Ordenny rait No.)	
	①Pilot Light (Round extended, red)					
Relays & Sockets	<ul> <li>②Pushbutton (Momentary, flush, white)</li> <li>③Pushbutton (Momentary, extended, black)</li> </ul>	HW1P-2Q HW1B-M1	LED / 24V 1N01NC	FB3W-413Z-A04004	FB3W-413Z-A04005	FB3W-413Z-A04006
Circuit Protectors	<ul> <li>Additional for the second secon</li></ul>	HW1B-M2 HW1S-2T	1N01NC 1N01NC	FD3W-4132-A04004	FD3W-413Z-A04003	FD3W-4132-A04000
	KIIUD, DIACK)	111110 21				
Power Supplies						

#### 5 Holes (Box Size: 200mm, Mounting Centers: 30mm) LED Illumination

	Symbol Specification	$\backslash$	Legend (1)	<without nameplate=""></without>	<without nameplate=""></without>	<without nameplate=""></without>
Controllers	Symbol Specification		Legend@	<without nameplate=""></without>	<without nameplate=""></without>	<without nameplate=""></without>
Operator			Legend 3	<without nameplate=""></without>	<optional marking="" plate=""></optional>	With nameplate "ON"
Interfaces			Legend@	<without nameplate=""></without>	<0ptional marking plate>	With nameplate "OFF"
Sensors	PLPLPBPBSS		Legends	<none></none>	<optional marking="" plate=""></optional>	With nameplate "HAND-AUTO"
AUTO-ID		Switch Part No.	Illuminated Voltage Contact Configuration	Part No. (Ordering Part No.)		
FB	<ul> <li>①Pilot Light (Round extended, red)</li> <li>②Pilot Light (Round extended, green)</li> <li>③Pushbutton (Momentary, flush, white)</li> <li>④Pushbutton (Momentary, extended, black)</li> <li>④Selector Switch (2-position maintained, knob, black)</li> </ul>	HW1P-2Q HW1P-2Q HW1B-M1 HW1B-M2 HW1S-2T	LED / 24V LED / 24V 1N01NC 1N01NC 1N01NC	FB3W-512Z-A05001	FB3W-512Z-A05002	FB3W-512Z-A05003

Symbol Specification		Legend	<without nameplate=""></without>
		Legend@	<without nameplate=""></without>
		Legend3	<without nameplate=""></without>
		Legend@	<without nameplate=""></without>
(SS)(PB)(PB)(PB)(PB)		Legends	<without nameplate=""></without>
	Switch Part No.	Contact	Part No.
	Switch Fart NO.	Configuration	(Ordering Part No.)
<ul> <li>①Selector Switch (2-position maintained, knob, black)</li> <li>②Pushbutton (Momentary, flush, green)</li> <li>③Pushbutton (Momentary, flush, green)</li> <li>④Pushbutton (Momentary, flush, green)</li> </ul>	HW1S-2T HW1B-M1 HW1B-M1 HW1B-M1 HW1B-M1	1N0 1N0 1N0 1N0 2N0	FB3W-512Z-A05004

#### Safety Precautions


- Turn off power before installation, removal, maintenance, and inspection. Failure to turn power off may cause electrical shocks or fire hazard.
- To avoid burning your hand, use the lamp holder tool when replacing the lamps.

#### Instructions

#### Installation

#### Panel Mounting

- 1. Installing the FB series from the front
- Using two M4 screws, install the base onto the panel. Recommended tightening torque: 1.4 to 2.0 N·m
- Determine the screw length in consideration of the base and panel thickness.
- Mounting screws are not supplied with the FB series. Use M4 mounting screws.



#### 2. Installing the FB series from the rear

- Insert four M4 tapped screws into holes for tapping screws on the back of the base (depth: 8 to 10 mm, tapping screw hole diameter: ø3.7 mm), and fasten the screws to a tightening torque of 1.3±0.1 N·m (Nitto Seiko M4-P-TITE).
- Mounting screws are not supplied with the FB series. Use M4 tapping screws (recommended screws: Nitto Seiko M4-P-TITE).
- The value of the recommended tightening torque has been confirmed with a M4 tapping screw (Nitto Seiko M4-P-TITE). When using other screws, check that the tapping screw hole is not damaged and the screw can be securely tightened.

#### 3. Installation using mounting bracket FB9Z-PK1

• Refer to installation instructions on C-020.

#### Installing and Removing the Switch/Pilot Light


• Refer to installation instructions for each unit.

#### Installing the Cable Gland

- Break a desired knockout to mount a cable gland using a hammer and a screwdriver, and install the cable gland.
- When breaking the knockout to make a cable gland hole, be careful not to damage the internal contact block.
- Note that cracks or burrs on the cable gland hole will degrade the waterproof characteristics.

#### Installing the Cover and Base

- Attach the cover to the base so that the TOP mark on the cover and base are in the same direction.
- Use cover mounting screws to attach the cover to the base. (Recommended tightening torque: 1.3±0.1 N·m)
- Make sure that the cover and the base are attached in the correct direction. Otherwise, the FB series may be damaged.




#### Installation using tapping screw hole inside the enclosure


- When using M3 tapping hole screws inside the enclosure, make sue to install the devices in consideration of the insulation distance and temperature rise. Damages caused by using devices other than those specified by IDEC are excluded from any warranty. Ensures installed with devices using tapping screw holes will not be UL or c-UL listed.
- M3 tapping screw hole (depth: 6 to 7mm, tapping screw hole diameter ø2.7m)
- Recommended tightening torque: 0.9 ±0.1 N·m, M3-P-TITE (Nitto Seiko)

## Applicable Crimping Terminal HW/TW Series


Non-insulated Terminal

Crimping terminal from lacksquare







IP20 terminal



#### Crrimping terminal from (B)




Dimensions for intalling insulated tube



· See HW series catalog pages for applicable crimping terminals.

#### Wiring Directions



APEM

Switches &

Pilot Lights

Safety Products

Explosion Proof

Terminal Blocks Relays & Sockets

```
Circuit
Protectors
```

```
Power Supplies
```

```
LED Illumination
```

Controlloro	
Comroners	

```
Operator
```

```
Interfaces
```

```
Sensors
```

2



Switches &

Pilot Lights

Emergency Stop Switches

Enabling

Switches

Safety Products

Explosion Proof

Terminal Blocks

Relavs & Sockets

Power Supplies

LED Illumination

Circuit

Protectors


AUTO-ID

attached.

**Control Boxe** 

#### Instructions

#### XW Series (Screw Terminal)



ø3.2mir 6.0max 3.0max


Insulated Terminal

\*1) When a spade terminal is used, the dimension is 4.7 to 5.9 mm.

- \* Be sure to install an insulating tube on the crimping terminal.
- \* When using crimping terminals for the XW series, use only one crimping terminal for each terminal.
- \* Make sure that the wiring does not contact the control stations.

#### Applicable Cable Gland

· Use cable glands with waterproof characteristics (IP65, TYPE 4X) which can be mounted on a panel thickness of 3 mm or more. \* Cable gland and Locking nuts are not



#### 1) When using flexible conduits (Example)

#### Flexible conduits: VF-03 (Made by Nippon Flex Co., Ltd.)

Controllers	Gland Port Size	Plastic Cable Gland	Metal Cable Gland
Operator	M20		RLC-103EC20 (Nippon Flex)
Interfaces	G1/2		RLC-103 (Nippon Flex)
Sensors	PG13.5		RBC-103PG13.5 (Nippon Flex)

#### When using multi-core cables (Example)

Gland Port Size	Plastic Cable Gland	Metal Cable Gland	
M20	Applicable gasket: GPM20 (LAPP, Germany)		
G1/2			
PG13.5	5301 5030 [Skintop-ST] Applicable gasket: GP13.5 (LAPP, Germany)	ABS-ロロPG13.5 (Nippon Flex)	

#### 3) Locking ring for cable gland (plastic, optional)

, , ,			
Gland Port Size	Locking Nut Part No. (made of plastic)		
M20	HW9Z-NM20 (IDEC)		
G1/2	HW9Z-G (IDEC)		
PG13.5	HW9Z-PG135 (IDEC)		

- The degree of protection of the cable gland examples described above is not NEMA TYPE 4X.
- . When using the FB series in North America, be sure to use UL approved plastic cable glands.
- Tighten cable glands to a torque of 3.0±0.3 N·m.
- \* Insufficient tightening of the cable gland may degrade the waterproof characteristics.
- \* Electric shock protection Class II is maintained only when a plastic cable gland is used.
- Determine the cable gland for a multi-core cable according to the outside diameter of the cable sheath.
- When wiring from the back of FB series, use the ø14 knockout on the back of the enclosure. A cable gland cannot be installed to the ø14 knockout.

#### Notes

#### **Applicable Wire Size**

• Determine the wire size in consideration of the applicable wire for switches/pilot lights and the applicable diameter of cables.

#### Wiring

- · Avoid foreign objects such as dust, liquid, and oil from entering the switch while connecting a conduit or wiring.
- Do not twist or pull the cable of flexible conduit with excessive force. Otherwise, the wire, FB series, and switches/pilot lights may be damaged.
- Because the FB series is not provided with a PG terminal, bonding circuits cannot be interconnected.

#### Installation of switches/pilot lights on 30 mm centers

• When mounting HW/TW series control units on 30mm mounting centers (close mounting), make sure to use a barrier (optional: HW-VU1) to secure the insulation properties of the terminal. The barriers (HW-VU1) can be easily pressed into the side of the contact block.

#### Operation

- · Avoid any contact with oil or coolants. Otherwise, the FB series may be damaged.
- Use the FB series for INDOOR applications only.


### **Contact Cover Box**

#### Specifications, applicable units, and wiring

Same as the standard control stations.

#### Installing XW series to the FB1WR-111Z contact cover

- Remove the contact block and the locking ring from the operator and check that the rubber gasket is in place. Insert the operator from panel front into the panel hole. Attach the rubber gasket and the base to the operator unit (place the rubber gasket between the panel and the base) and tighten the locking ring using locking ring wrench MW9Z-T1. Recommended tightening torque: 2.0 N·m
- Attach the contact block to the operator. After wiring, attach the cover to the base using four cover mounting screws. Recommended tightening torque: 1.3±0.1 N·m
- Use a nameplate if necessary.
- Determine the panel thickness by excluding the thickness of the base (2.0 mm) and accessories (if used) from the maximum panel thickness for the switch/pilot light.



#### Notes

- Do not expose the cable to excessive force, otherwise failure or damage may be caused. When mounting strength is needed, insert M4 tapping screws from the front of the panel (screw tightening depth: 8 to 10 mm tapping screw hole: ø3.7 mm)
- Determine the mounting hole centers referring to the dimensions of the control stations.

### APEM

Switches & Pilot Lights

Emergency Stop Switches Enabling Switches

Safety Products

Explosion Proof

```
Terminal Blocks
```

```
Relays & Sockets
```

```
Circuit
Protectors
```

```
Power Supplies
```

LED Illumination

```
Controllers
```

```
Operator
Interfaces
```

```
Sensors
```

```
AUTO-ID
```

Instructions

## **Mounting Bracket**

**Hook Mounting** 

- Attach the FB9Z-PK1 mounting bracket on the FB series with the supplied screws (two M4 tapping screws).
- Recommended tightening torque: 1.3±0.1 N·m
- Do not tighten the FB9Z-PK1 onto the FB series with excessive force. The tapping screw hole may be damaged and may not securely hold the FB series.

#### **Frame Mounting**

• The FB9Z-PK1 can be used as frame mounting brackets by attaching two FB9Z-PK1 as shown below.

**FB** Series

FB9Z-PK1


Two M4 Tapping Screws (supplied)

(Depth: 10mm)

Two M4 Tapping Screw Holes

Depth


10mm



• Attach the FB9Z-PK1 on the FB series with the supplied screws (two M4 tapping screws).

Recommended tightening torque: 1.3±0.1 N·m.


- Do not tighten the FB9Z-PK1 onto the FB series with excessive force. The tapping screw hole may be damaged and may not securely hold the control station.
- Using two M6 screws, fasten the FB9Z-PK1 securely on the frame. Recommended tightening torque: 5.0±0.3 N·m



- M6 mounting screws and nuts are not supplied with the FB9Z-PK1.
- The value of the recommended tightening torque for M6 screws has been confirmed with a hexagon socket head screw. When other screws are used and tightened to a smaller torque, make sure that the screws do not become loose after mounting.

## Dimensions

All dimensions in mm.



Mounting Hole

Γ

59.5

10

FB Series

FB2 (140mm)

140

18.5

12

FB3() (200mm)

200

18.5

12

1) Hook Mounting

M6 Screw 76		59.5	10
+	$\setminus$		FB
	$  \setminus$	FB1 (76mm)	FI (1-
	L	76	
	С	93	
	D	114	

FB Series					
FB1  (76mm)	FB2 (140mm)	FB3 (200mm)			
76	140	200			
93	156	216			
114	177	237			

# **Control Boxes**

APEM

Switches &

Pilot Lights

Emergency

Switches

Stop Switches Enabling

Safety Products

Explosion Proof

Terminal Blocks

Relavs & Sockets

Power Supplies

LED Illumination

Controllers

Operator

Interfaces

Sensors

AUTO-ID

Circuit

Protectors

## **DIN Rail Adapter**

Instructions

#### Mounting

#### 1) Installing the FB9Z-PK3 DIN Rail Adapter


- To attach the FB9Z-PK3 on the FB series, position the positioning hole of the FB9Z-PK3 with the positioning boss in the enclosure using four M3 tapping screws (supplied) as shown in the figure below. Recommended tightening torque: 0.9±0.1 N·m
- Do not tighten the FB9Z-PK3 onto the FB series with excessive force. The tapping screw hole may be damaged and may not securely hold the control station.

#### 2) Installing the DIN Rail

. To attach a DIN rail, use plain washers and spring washers on two M5 screws and tighten firmly.

Recommended tightening torque: 2.0 ±0.1 N·m


- DIN rail mounting screw (M5)
  - Screw length: (spring washer thickness + plain washer thickness + DIN rail thickness) + 3 to 5 mm




- 3) Mounting Switches/Pilot Lights on DIN Rail
- · Refer to each instruction sheet.

#### 4) Installing the Separate Mounting Transformer

- After attaching the FB9Z-PK3 on the FB series, attach the separate mounting transformer on the FB9Z-PK3, using plain washers and spring washers on two M3 screws as shown in the figure below. Recommended tightening torque: 0.5 to 0.8 N·m
- Separate mounting transformer mounting screw (M3) Screw Length: (Spring washer thickness) + (Plain washer thickness) + 7 to 10 mm




- M3 screws, spring washers, and plain washers are not supplied.
- Do not tighten the screw with excessive force. The screw hole and the separate mounting transformer may be damaged.




#### FB9Z-PK3 Dimensions

All dimensions in mm



- M5 screws, spring washers, and plain washers are not supplied.
- The length of DIN rail must be within the effective internal dimensions.
- Do not tighten the M5 screw onto the FB9Z-PK3 with excessive force. The screw hole may be damaged and may not securely hold the FB9Z-PK3.



# **Control Boxes**

#### APEM

Switches & Pilot Lights

Emergency Stop Switches Enabling Switches

Safety Products

Explosion Proof

Terminal Blocks

Relays & Sockets

Circuit Protectors

Power Supplies

LED Illumination

Controllers

Operator Interfaces


Sensors

AUTO-ID

#### Instructions



FB9Z-PK3 Installation Positions



Note: Only one DIN rail adapter can be used for FB1 (76mm).

#### 5) Other Precautions

- Rated current of terminal blocks depends on operating conditions such as wire type, number of bundle wires, and ambient temperature. Check the specifications of terminal blocks carefully, and use terminal blocks within the specification values. Otherwise electric shock or fire hazard may be caused.
- FB series is rated as Class II protection against electric shock (no reliance on installation protective measures, according to IEC 61140). When using a blank front enclosure as a junction box and grounding is necessary, provide appropriate grounding, for example installing a grounding terminal block inside the enclosure.
- . For wiring, refer to the instructions of the FB series and switches/pilot lights used.